

The Brick Mailbox Repair Guide

by Travis Nech

Free edition — championbrickrepair.com

The Brick Mailbox Repair Guide

From Leaning and Cracked to Standing Straight — A Homeowner's Handbook

By Travis Nech

Owner, Champion Brick Repair — Dallas-Fort Worth, Texas

A Note on How This Book Was Made (AI Disclosure)

This book was written with the assistance of artificial intelligence, working from the field experience, methods, and standards of Travis Nech, a Texas mason with decades of hands-on brick and masonry work in Dallas-Fort Worth. AI tools helped draft, organize, and edit the text. The judgments in it — what fails, why it fails, and what a proper repair looks like — are the author's own, drawn from real jobs. On any platform that asks whether this book contains AI-generated content, the honest answer is yes, and that is the answer we give.

Introduction: The Smallest Masonry Structure You Own

A brick mailbox is the smallest masonry structure on your property and the one everybody sees. It stands at the curb like a nameplate for the house. It is also, quietly, a complete masonry structure in miniature: it has a footing, brick masonry laid in mortar, a steel or masonry door surround, a cap that must shed water, and — in Texas — it sits in expansive clay soil that spends the year trying to tip it over.

Because it is small, people treat its problems as small. A lean is "character." Cracks are "just cosmetic." Then one morning the door will not close because the box has rotated, or a whole corner sheds brick after a freeze, or a delivery truck's mirror finishes what soil movement started — and the homeowner discovers that the little structure at the curb costs real money to put right, and that half the people offering to fix it plan to do it wrong.

I run a brick repair company in Dallas-Fort Worth, and mailboxes are steady work for us — knocked down, leaning, cracked, spalling, and rebuilt. This book is everything we have learned, written for the owner standing at the curb deciding what to do: how a brick mailbox is actually built, the full catalog of what goes wrong and why, the honest line between repair and rebuild, what each job should involve step by step, how brick and mortar get matched so a repair disappears, the postal rules and neighborhood realities you have to respect, and how to hire the work — or judge a quote — without getting taken.

Small structure. Real masonry. Let's treat it that way.

Chapter 1: Why Brick Mailboxes Fail

A brick mailbox fails for one of five reasons, and naming the right one matters because each has a different fix.

1. The footing is too small, too shallow, or missing. This is the original sin of mailbox construction. A brick mailbox is heavy — several hundred pounds of masonry concentrated on a small footprint. Set on a thin pad poured at grade, or worse, brick laid nearly on the dirt, it will settle and tilt as the soil moves. In expansive clay, a shallow footing rides the shrink-swell cycle: wet season lifts one corner, dry season drops it, and the structure ratchets a little further out of plumb every year. Most leaning mailboxes are not failing brickwork. They are failing foundations in miniature — and any repair that ignores the footing is redecorating a lean.

2. Water gets in from the top. The cap is the roof of the structure. A cap that is cracked, flat instead of sloped, or missing its mortar seal lets rain pour straight into the masonry core. Water inside brickwork does three kinds of damage: it softens mortar over time, it rusts any steel it reaches, and in a freeze it expands and pops brick faces off — the spalling you see as flaked, crumbling brick surfaces. The majority of "my bricks are falling apart" mailboxes we inspect have sound brick and a failed cap.

3. The soil moves and the box rides it. Texas clay again: it shrinks in drought and swells when wet, and a mailbox at the curb often sits near a street-side drainage path, a sprinkler head, or a thirsty tree. One side of the footing stays wetter than the other, the ground heaves unevenly, and the box leans toward the dry side. This is why two identical mailboxes on the same street lean in different directions — the water story at each curb is different.

4. Something hits it. Cars, delivery trucks, trailers, and the occasional teenager with a bat. Impact damage ranges from a cracked corner and a bent door to a box knocked clean off its footing. The telling question with impact is whether the footing and the core survived — a box can look destroyed and be structurally fine below the damage, or look merely cracked and be split through.

5. The metal dies first. The door, its frame, the flag, and the box insert itself are steel or plastic living outdoors inside a masonry oven. Rust claims the door frame; the door sags or will not latch; the insert cracks. Owners often call this "my mailbox is broken" when the masonry is perfect. Good news: this is the cheapest failure on the list, and Chapter 5 covers it.

Read your mailbox's story before you price its repair. The chapters that follow teach you how it is built, then walk the damage catalog, then the decision.

Chapter 2: Anatomy of a Brick Mailbox

From the ground up, a properly built brick mailbox has six parts. Knowing them lets you follow any quote line by line.

The footing. A reinforced concrete footing below grade — in North Texas, typically at least twelve inches deep and several inches wider than the masonry on every side, sized for the soil. This is the part nobody sees and the part that decides whether the box stands straight in year ten. A mailbox built without one is a countdown.

The pedestal. Brick laid in running bond (each course offset half a brick) around a core — either hollow block, poured concrete, or solid masonry — rising from the footing to the box height. Corners are interlocked, not butted. The mortar joints are tooled — slightly compressed and shaped — which seals the surface and sheds water. Flat-smeared or deeply raked joints on exterior work invite water in; joints should be full and tooled concave or weather-struck.

The box insert and its surround. The mail tube itself — steel or heavy plastic — set into the masonry at the postal height, with a masonry or stone surround framing the door opening. The insert must sit level and be supported so its weight and the door's daily swinging do not work it loose. The newspaper tube or lower box, where fitted, is part of this assembly.

The door and flag. The door closes against a frame; its latch is the daily wear point. The red flag signals outgoing mail.

Both are replaceable hardware — but the frame is often mortared in, which is why "just a door" sometimes is not just a door.

The cap. A stone, precast, or brick cap — sloped to shed water, overhanging the pedestal slightly with a drip edge so water falls clear of the brick face instead of running down it. The cap is bedded in full mortar and its joints sealed. This is the structure's roof and its most common failure point.

The address numbers. Set into the face, mounted on a stone or plaque, or applied to the door. Small thing — but on a rebuild, matching the neighborhood style and keeping numbers legible at street distance is part of doing the job like you live there, which, in our case, we do.

Overall height and setback are not the builder's whim — the Postal Service sets standards for curbside boxes, covered in Chapter 8. A well-built box is a small monument to doing simple things in the right order: footing, pedestal, box, cap, numbers.

Chapter 3: The Damage Catalog

Here is everything we get called about, in the order we usually find it, with what each one means.

The lean. Put a level on it, or stand back and compare it to the streetlight poles and the neighbor's box. A lean under about an inch at the top, stable for years, is often an old box that settled once and stopped — monitor it. A lean that is growing, or over two inches, is a footing-and-soil story (Chapter 1, reasons 1 and 3), and no amount of fresh mortar will fix it. Look for the companion signs: a gap opening between the footing and the soil on the high side, soil heaped against the low side, a door that has started binding in its frame. The door binding is your early-warning system — the box is rotating and the square opening is becoming a diamond.

Cracks. Read them like a map:

- Stair-step cracks through the mortar joints mean differential movement — one part of the structure moving relative to another. On a mailbox, usually a footing corner dropping.
- A vertical crack through brick and joints alike usually means impact or a freeze split — force, not settlement.
- Hairline cracks in the cap only mean the cap's mortar is aging; a reseal item, not a structural alarm — if caught before water gets a season inside.

- Cracks radiating from the door frame corners mean the box insert is moving or its surround was never properly supported.

Spalling and flaking brick. Brick faces popping off in scales or chunks = water inside the brick froze, expanded, and took the face with it. Spalling bricks cannot be patched back; they are replaced. Widespread spalling across the whole box usually means the cap failed long ago and the whole structure got wet from the top down — repair the cause first, then count the brick.

Mortar loss. Joints recessed, sandy, or missing to a depth of a quarter inch or more mean the mortar has reached its service life or water has been working the wall. The cure is repointing — Chapter 5 — and it is the single best money you can spend on an aging box, because sound joints are the wall's raincoat.

Door, latch, and insert problems. Door will not stay closed, sags, is rusted through at the hinge; flag missing or bent; insert cracked or the carrier has left a note about the box. Sometimes hardware. Sometimes the first symptom of the lean. Check plumb before you blame the door.

The strike. Fresh impact has a signature: bright, clean fracture faces, debris in the street, damage concentrated on one corner or one side. Photograph everything before anyone touches it — your insurance company and, if it comes to it, the other driver's will both want the before pictures. Then make it safe: a struck box can be a pile of loose brick balanced on a footing.

Water stains and white crust. Dark streaking below the cap means water runs down the face (no drip edge, failed cap joint). White powdery crust — efflorescence — means water is moving through the masonry and leaving salts behind. Both are water telling you its route. Follow it to the entry point; that is your repair.

Chapter 4: Repair or Rebuild? The Honest Decision

The decision turns on two things: the footing and the core.

Repair is right when: the footing is sound and the box is plumb (or its small lean is old and stable), the core masonry is intact, and the damage is in the repairable list — mortar joints, the cap, individual spalled or cracked brick, the door and hardware, localized impact damage above a sound base. Most mailboxes we are called about live here, which is good

news: honest repairs are a fraction of rebuild money.

Rebuild is right when: the lean is pronounced or growing (the footing has failed or never existed), the structure is split through the core, impact has destroyed the pedestal, spalling and mortar loss are so widespread that the remaining sound material is the exception, or the box was built so far out of postal spec or so far into the street's swing path that it will keep getting hit. A rebuild is also the honest answer when the repair quote starts approaching rebuild money — you should hear that sentence from your contractor before you have to say it yourself.

The middle path — reset and rebuild the top: sometimes the footing is sound but the pedestal above it is shot, or the box was knocked off a good footing. Then the right job is: demo to the footing, verify the footing, rebuild the pedestal on it. Cheaper than a full rebuild, honest in a way "patch it" is not.

What nobody should sell you: shimming a leaning box with gravel and fresh soil and calling it straightened (it will re-lean on the same footing that failed); re-mortaring cracks on a moving structure without addressing the footing (the crack is the messenger, not the problem); or a "rebuild" that quietly reuses a failed footing because digging is the hard part. And a note on straightening: a mailbox that has leaned as a unit on an undersized footing cannot be jacked back and trusted — the footing is the failure. Rebuild the base, then the box stands straight because it finally has something straight to stand on.

One more decision factor owners forget: **the match**. If your box is part of a matched neighborhood set — same brick, same cap, same numbers style — a repair that preserves the original brick has value a rebuild has to work to equal, because brick lines get discontinued and a 20-year-old brick may not be buyable at any price. Chapter 7 covers matching; just know it can tip a close call toward careful repair.

Chapter 5: The Repair Playbook

Six repairs cover nearly every sound-box problem. Here is what each one properly involves.

1. Repointing. The failed mortar is raked or ground out to a depth of about twice the joint's width — no less — the dust washed out, and new mortar, matched to the original in strength and color, is packed in layers and tooled to match the existing profile. The non-negotiables: mortar must never be harder than the brick around it (hard modern mortar

against softer brick forces freeze damage into the brick faces — the joint is meant to be the sacrificial layer), and a surface smear over old mortar is not repointing — it is frosting, and it will peel within a season or two.

2. Cap reseal and repair. Cracked cap joints are raked and resealed; a cracked cap stone is replaced or, where the stone is sound but its bedding failed, lifted, rebbed in full mortar, and resealed. The finished cap must slope, overhang, and drip clear of the face. If the design has no drip edge, cutting one into the cap's underside is a small touch that ends face-streaking for good.

3. Brick replacement. Spalled or split bricks come out — individually, without wrecking their neighbors — and matching brick go in, bedded and jointed to match. On a mailbox face, two or three replaced bricks are invisible when the match is right and glaring when it is wrong; Chapter 7 is the difference.

4. Door, frame, and hardware. A rusted or bent door is replaced; where the frame is mortared in, the surrounding joints are cut carefully and repointed after. Hinges and latches are the wear points — stainless or galvanized hardware buys years. A sagging door gets diagnosed before it gets replaced: if the frame is square and the box is plumb, it is hardware; if not, it is Chapter 4's conversation.

5. Localized impact repair. Broken units at a corner come out back to sound, interlocked masonry — the new work must key into the old at the corners, not stack in a straight vertical seam, which is a crack waiting for its moment. If the impact reached the insert or frame, they are reset or replaced as part of the same job.

6. Efflorescence and stain cleanup. Mild efflorescence brushes off dry and usually stops once the water route is fixed. The sequence matters: fix the water first, clean second, or you will be cleaning forever.

Every repair above ends the same way: joints tooled, faces washed down, debris gone, and the site left cleaner than a curb has any right to be. That is not vanity. It is how you can tell the crew cared about the invisible parts too.

Chapter 6: The Rebuild Playbook — Footing to Capstone

When the decision is rebuild, here is the full sequence, so you can follow a quote — or a crew — step by step.

Step 1 — Demo and salvage. The old structure comes down. If the brick was special — an old neighborhood match — sound bricks are cleaned and set aside to blend into the new face. The old footing comes out if it failed; a verified-sound footing may stay (see Chapter 4's middle path), and your contractor should show you why it qualifies.

Step 2 — The footing. Excavated to firm soil below the soft surface layer — in our clay country, plan on at least twelve inches deep — sized several inches wider than the pedestal on all sides, with steel reinforcement, poured in one go and leveled. This unglamorous gray square is the entire reason the new box will be plumb when your kids are grown. If a quote's footing line reads "concrete pad," ask the depth. The answer tells you the job.

Step 3 — Placement check before masonry. Confirm the setback and height against postal standards (Chapter 8) now, while it costs nothing. A box rebuilt six inches too close to the curb is a box that meets another mirror.

Step 4 — The pedestal. Brick laid in running bond around a solid core, corners interlocked, every joint full, courses checked for level and plumb as they rise. Mortar mixed for exterior masonry — never bagged "patch" products — and matched to the house brick's mortar color where the box should read as part of the property.

Step 5 — The insert and surround. The mail tube set level at postal height, supported independently so the masonry carries no surprises, surround framed square — because the door's life depends on that square. Newspaper tube if fitted. Flag mounted.

Step 6 — The cap. Stone or precast cap, sloped, overhanging with a drip edge, fully bedded, joints sealed. The cap is not decoration that happens to be on top; it is the roof. Treat its line in the quote accordingly.

Step 7 — Numbers and finish. Address numbers mounted legibly from the street, joints tooled, faces cleaned, the grade around the footing restored so water sheds away from the base, and sod or bed material put back. Then the final photograph — a good crew takes one, because a straight, matched, clean mailbox is an advertisement that never stops running.

Timeline reality: a quality rebuild is commonly two visits — footing and pedestal, then cap and finish after initial cure — or a long single day plus a return for cleanup and numbers. A crew promising a full rebuild, footing and all, in a couple of hours is pouring your footing at grade and skipping the cure, and Chapter 1 already told you how that story ends.

Chapter 7: Matching Brick and Mortar So the Repair Disappears

The whole game in visible masonry repair is the match. A structurally perfect repair in the wrong color is a scar the street reads every day. Here is how professionals approach it.

The brick. Start with what comes out: a spalled brick in hand, carried to the brick yard, beats any photo. Brick is identified by size (modular vs. queen vs. king — measure, don't guess), color range (brick is a range, not a color — every run varies, and a good match picks from the range), texture (smooth, wire-cut, tumbled), and age character. Discontinued lines are matched from reclaimed stock or by blending the closest current brick with units salvaged from the structure's least visible face — an old mason's trick: steal from the back to fix the front, and put the closest new brick where nobody looks.

The mortar. Mortar color is set by its sand more than its cement — the same mix with a different sand is a different color on the wall. A proper match is made by test panels: small batches with adjusted sand and pigment, allowed to dry fully (wet mortar lies about its color by several shades), and compared against the existing joints in daylight. Strength matters as much as color: the new mortar must be no harder than what it joins and no harder than the brick — on older, softer brick, that means a softer, higher-lime mix, and a contractor who only carries one hard mix in the truck is a hazard to old masonry.

The joint profile. Match the tooling — concave, weather-struck, flush — and the joint width. A perfectly color-matched joint tooled to a different profile still reads wrong, because joints are shadow lines and the shadow is different.

The blend. New work gets distributed — units feathered across the repair area rather than placed in one obvious block, and the finished wall washed so the new joints and the old read as one wall after a season of weather. Set expectations honestly: a match that is 95 percent on day one is usually invisible by the end of the first year, as dust and weather marry the surfaces. Anybody promising a showroom-perfect match on an aged wall on day one is selling something.

For the homeowner, the practical takeaway: give your mason a loose brick if you have one, point at the exact joints you want matched, and ask to see the dried test panel before the

wall gets pointed. Good masons welcome it. It is their craft on display.

Chapter 8: The Rules — Postal Standards, Streets, and Neighborhoods

A brick mailbox lives in three jurisdictions at once: the Postal Service's, the city's, and your neighborhood's. A rebuild that ignores any of them can cost you a second rebuild.

Postal standards. USPS sets standards for curbside mailboxes: the box must be an approved design, installed so the carrier can serve it from the vehicle without leaving the seat. The standing guidance places the bottom of the box (or the mail entry) roughly 41 to 45 inches above the road surface, set back so the door front sits about 6 to 8 inches behind the curb face or road edge. Approach and departure must be clear. Treat these numbers as the design targets — and confirm with your local post office before a rebuild sets them in stone, because local practice and street layout vary, and the carrier who serves your route is the final inspector. A masonry surround must not obstruct the door's full swing or the carrier's reach.

Safety and the street. A mailbox is a fixed object in the roadside environment. Use common sense in placement: the postal setback exists partly so the box is out of the traffic path; do not build it closer for convenience. Some jurisdictions restrict massive masonry structures in the right-of-way; a standard residential brick mailbox on the established line, replacing like for like, is routine in our area — but a first-time masonry build on a new lot should get a quick call to the city before the footing is dug.

HOA and neighborhood rules. Many neighborhoods govern mailbox design — the matched streetscape is often the point: same brick family, same cap style, same number plaque. If you have an HOA, get the standard or approval before the demo, especially for anything that changes the look. If your street has a uniform builder-installed design, the documents usually live with the HOA or a neighbor who has already done this dance.

After a strike. If a vehicle knocks your box down, you generally have a claim against the driver's insurance for the full cost of like-kind replacement. Photograph before cleanup, save the quote and invoice, and get the police report number where one was filed. Your mason's paperwork — a written quote describing the structure like-kind — is your claim's

backbone.

None of this is red tape for its own sake. The box belongs to you; the mail slot belongs to a federal routine; the curb belongs to the city; the look belongs partly to the street. A good rebuild respects all four, once, and stands there unbothered for decades.

Chapter 9: What It Costs and What Moves the Number

Mailbox work is small-job work, and small jobs carry the fixed costs of any job — a crew, a truck, materials, disposal — spread over a small structure. Prices vary by market and season; use the factors below to read a quote, and treat any printed figure, here included, as orientation rather than a promise.

What you are paying for, by job type:

- **Hardware and door work** is the entry tier — the cheapest call in this book, priced mostly as labor plus parts — provided the masonry behind it is sound.
- **Repointing and cap work** is mid-tier handwork: a day or less of a mason's time, priced by the size of the box and the depth of joint failure. It is also the highest-value money in mailbox ownership (Chapter 3: joints are the raincoat; the cap is the roof).
- **Partial repairs** — brick replacement, a corner rebuild, insert reset — price by the units involved and the matching effort. A discontinued brick that takes a yard run to match costs more than the masonry does.
- **Full rebuilds** carry the footing, full masonry, insert, cap, and finish. The footing and the matching are where the spread between quotes usually lives: the cheap quote pours a pad, the right quote digs a footing; the cheap quote grabs any red brick, the right quote matches yours.

The three quote questions that expose everything: "How deep is the footing?" — "Where does the brick come from, and can I see a sample against my box?" — "Is the cap stone or precast, and is it in this number?" A contractor who answers all three crisply is pricing your job. One who waves at them is pricing his morning.

And the standing warning of every book in this series: the low bid on masonry is usually a bid on doing less — less depth, less match, less cure. On a structure you will look at every day, at the curb, for twenty years, less is the most expensive thing you can buy.

Chapter 10: Hiring a Mason — and Protecting Yourself

Finding the right hands. Brick mailboxes are specialist work hiding in plain sight: too small for big firms to chase, too structural for handymen to fake for long. The right hire is a masonry or brick-repair company that does mailboxes as a stated line of work — ask how many they have repaired and rebuilt, and ask to see photos of mailboxes, not just walls. A company that repairs brick daily already owns the matching skills in Chapter 7; the mailbox is their craft at curb scale.

The quote should state: scope (repair items or rebuild, named), footing depth if rebuilding, brick source/match method, mortar match method, cap type, insert/door inclusion, haul-off of debris, and the timeline. Anything not in the quote is not in the job — get changes in writing before they happen, not after.

Red flags: a "straightening" promise on a failed footing; a rebuild quote with no footing line; mortar described as "the strong stuff" for old soft brick; a full rebuild promised in a couple of hours; cash-only with no paperwork (your insurance claim in Chapter 8 needs that paperwork); and any bid given without the bidder walking to the curb and laying a level on the box.

While the work runs: you should see the footing hole before it is poured — it is your one chance to verify the depth you paid for; the brick sample against your house before it is laid; and dried test mortar if matching matters. None of this makes you difficult. It makes you the customer every good mason prefers: one who can see the difference.

After the job: keep the invoice and a photo set with your house papers. If a strike or a sale ever raises the question "what is that box and what did it cost," you will have the answer, and the next owner inherits a structure with a documented footing instead of a mystery at the curb.

Appendix: The Ten-Minute Mailbox Check (Twice a Year)

Each spring and fall:

- Lay a level on the side of the pedestal — note the lean, or the lack of it, in your phone with the date.

- Test the door: full swing, clean latch. A new bind is movement talking.
- Read the cap: cracks, open joints, rocking. Reseal beats rebuild by years.
- Run a screwdriver lightly across the joints: powdering or recessed joints go on the repoint list before they reach a quarter inch.
- Check for new cracks — photograph with a coin for scale; compare next season.
- Confirm the numbers are legible from a slow-moving car, and the flag works.
- Clear soil and mulch away from the base; the footing line should breathe, not bury.
- Glance at the sprinkler pattern: a head soaking the box daily is a slow leak against your own wall.

Ten minutes, twice a year, and your mailbox will never surprise you. It is the smallest structure you own — and with a footing under it and a cap over it, one of the longest-lived.

The Brick Mailbox Repair Guide — Travis Nech, Champion Brick Repair. Draft manuscript, October 2026. AI-assisted writing; see the disclosure at the front of this book.