

The Lime Mortar Revival

by Travis Nech

Free edition — championbrickrepair.com

THE LIME MORTAR REVIVAL

A Texas Craftsman's Field Guide to Historic Mortar: Lime Mixes, Mortar Matching, and Repointing Old Brick Without Destroying It

Travis Nech

Copyright

© 2026 Travis Nech. All rights reserved.

ISBN pending KDP assignment.

No part of this book may be reproduced in any form without written permission from the author, except for brief quotations in reviews and articles.

The guidance in this book is based on fifty years of hands-on field experience in brick, masonry, and mortar work across Texas. It is educational material, not professional advice for any specific building. Where structural questions arise, hire a licensed structural engineer.

Table of Contents

- Chapter 1: Why Old Mortar Dies — and Why New Mortar Kills Old Brick
- Chapter 2: Reading Historic Mortar Like a Map
- Chapter 3: Lime, Explained — Hydrated, Fat, and Hydraulic
- Chapter 4: Mixing the Match — Building the Right Mortar for Old Walls
- Chapter 5: Color Matching at the Restoration Level
- Chapter 6: The Secretary's Standards, in Plain English
- Chapter 7: Raking and Grinding Without Chewing the Brick
- Chapter 8: Striking the Joint — Tooling That Matches the Old Work
- Chapter 9: Curing in Texas Weather
- Chapter 10: Soft Brick, Stone, and Adobe — Special Cases
- Chapter 11: The Business of Historic Repointing

- Chapter 12: Mistakes That Cost Real Money
 - Conclusion: The Wall You Leave Behind
 - Resources & Next Steps
 - About the Author
-

Chapter 1: Why Old Mortar Dies — and Why New Mortar Kills Old Brick

There is a particular kind of damage I see on old houses that tells me the whole story before I ever touch a trowel. The brick faces are blowing off. Not crumbling from the inside — the faces are popping, flaking, coming off in sheets like sunburned skin, while the mortar joints right next to them are hard as rock and perfectly intact. And every time I see it, I know somebody repointed that wall with the wrong mortar. Somebody came along with a bag of modern Portland cement mortar, raked out the old joints, and packed in something five times harder than the brick itself. Then the wall did exactly what walls do when you give them the wrong materials: it punished the softest thing left.

I want to start here, at the very beginning, because this one idea decides everything else in this book. A masonry wall is a system. The mortar, the brick, and the movement were all designed to work together, and when the people who built the wall chose their materials, they made a decision that most modern masons never even think about: they made the mortar the weak link on purpose.

Walk through any neighborhood with houses from the 1800s or early 1900s and look at the original mortar joints. They are soft. You can scrape them with a screwdriver. In some old houses you can practically dig the mortar out with your fingernail after a century of weather. People see that and think the old mortar failed — that it was just a primitive material from before we knew better. That is exactly backwards. The old mortar was never supposed to be hard. Lime mortar was built to be the sacrificial part of the wall. That is its job. When moisture gets into a wall and freezes, when the building expands in the summer heat and shrinks in the winter cold, when the foundation settles a fraction of an inch and the wall has to flex or find somewhere to give — the lime mortar gives. It cracks a little. It crumbles a little. It takes the punishment so the brick doesn't have to. And here is the beautiful part of the design: when lime mortar cracks, it can actually heal itself over time. Moisture moves through the joint, dissolves a little of the free lime still sitting in there, and deposits it back into the crack. Lime walls have been quietly repairing themselves for hundreds of years in buildings that

are still standing all over Europe and the eastern United States.

Now put Portland cement into that equation. Portland mortar — the gray stuff in the bag at every supply house — cures hard and it cures rigid. Put it into the joints of an old soft-brick wall and you have flipped the design upside down. The mortar no longer gives. So when the wall moves, when water gets in and freezes, the force has to go somewhere, and the somewhere it goes is the brick faces. The mortar stays perfect and the brick disintegrates around it. I have stood in front of walls where you can read the history of the mistake like a book: hard gray joints, spalled brick faces, the edges of the brick crumbling away from the mortar that is supposed to hold them. It is called a hardness mismatch, and it is the single most common cause of catastrophic damage on historic brickwork in this country.

Let me slow down and describe the autopsy, because if you are going to work on old buildings, you need to be able to read one. The first sign is usually efflorescence — that white powdery bloom on the brick faces. Water is getting into the wall and it can't get out through the hard cement joints, so it pushes out through the brick itself, carrying dissolved salts with it. The salts crystallize just under the surface of the brick, and the crystal growth pries the face loose. Then you get spalling: the faces start to delaminate, flaking off in layers, sometimes popping off whole chunks the size of a playing card. The brick starts to look like it has been sandblasted, the sharp edges round off, and the wall takes on that pitted, eroded look that makes people think the brick is just old. The brick isn't just old. The brick is being killed by its own mortar.

The second act of the autopsy is the joint itself. Portland cement is not only hard — it is relatively impermeable compared to lime. A lime mortar joint breathes. It lets moisture that gets into the wall migrate back out. A cement joint seals the wall's escape routes, so moisture that would have evaporated through the joints instead sits inside the wall, saturating the brick from behind. In a Texas summer, that trapped moisture turns into a pressure cooker. In the rare hard freeze, it turns into an ice wedge. Either way, the brick loses and the mortar wins, which is the exact opposite of how the wall was designed to work.

And the third thing the autopsy shows is what the repointing did to the wall's movement. Old buildings move. They were built to move a little — wood framing swells and shrinks, foundations shift with the soil, the whole structure breathes with the seasons. Lime mortar accommodates that movement because it never gets truly rigid; it stays slightly flexible for its whole life. Cement mortar goes hard and stays hard, so a

wall that used to flex at its joints now has to crack somewhere else — usually straight through the middle of the bricks, in stair-step patterns that run across the wall instead of following the joints. If you see cracks running through brick faces instead of through mortar joints, ask when the wall was repointed. The answer usually explains everything.

So when does old lime mortar actually die on its own, without anybody's help? It does happen. A century of weather will erode even good lime mortar, especially at exposed locations — parapets, chimneys, the windward side of the building, anywhere water concentrates. Sand in the old mix that was too fine or too rounded will wash out faster. A bad original mix — too little lime, or lime that was poorly slaked — gives up early. Freeze-thaw cycles in places that get real winter will chew the joints from the outside in. And ground-level moisture wicking up from the foundation will rot the lowest courses over decades. But here is what matters: natural lime mortar death is slow, it is graceful, and it looks like erosion — the joints getting gradually shallower and softer. What I described earlier — hard joints, destroyed brick — that is not natural death. That is murder. That is what happens when the repointing mortar is harder than the masonry it is supposed to protect.

This is the principle that runs the entire book: match the mortar to the wall, not to the hardware store. The softness of lime mortar is not a defect to be fixed with something stronger. It is the load-bearing philosophy of every historic wall ever built. The mortar is the cushion. The mortar takes the hit. The brick survives because the mortar sacrifices. Every chapter from here on is just the working detail of that one idea — how to read what is already in the wall, what kind of lime to put back, how to mix it, how to place it, and how to cure it so it can go back to doing its quiet job for the next hundred years.

One more thing before we move on, and this one is a boundary I hold for every job I touch. If you are looking at a wall where the damage goes deeper than the mortar — leaning walls, bulging wythes, cracks you can put your finger into, anything where the structure itself is moving — that is beyond a mortar question. That is a structure question, and structure questions belong to a structural engineer. I have fifty years of laying brick and matching mortar, and I know exactly where my lane ends. Nothing in this book replaces an engineer's judgment on a building that is moving. Get the engineer first, then come back to the mortar.

Before I close, I want to give you one more picture of the system at work, because seeing it once makes the whole idea stick. Picture two walls, side by side, same soft red brick, same age, same weather. Wall A was repointed thirty years

ago with lime mortar matched to the original. Its joints are a little weathered now — they're softer at the surface, maybe eroded back a sixteenth of an inch in the most exposed spots — but the brick faces are sharp and whole, and the wall looks like a dignified old building. Wall B was repointed the same year with Portland cement. Its joints look perfect. Not a crumb out of place. And its brick faces are gone — spalled, pitted, rounded, the whole surface of the wall receding while the joints stand proud like the mortar is the only thing that survived. That is the sacrificial design working exactly as intended in one wall and exactly backwards in the other. The mortar in Wall A did its job: it gave, it eroded, it took the weather on itself, and the brick lived. The mortar in Wall B refused to do its job, so the wall made the brick do it instead. Same brick, same weather, same thirty years. The only difference was the mortar. That is why this chapter matters more than anything else you will read in this book: pick the wrong mortar and nothing else you do — not your technique, not your tools, not your care — can save the wall. Pick the right one and the wall takes care of itself.

Chapter 2: Reading Historic Mortar Like a Map

Before you touch a single joint on a historic building, you read it. The existing mortar is a map of everything the wall has been through and everything it needs, and a mason who can't read it is working blind. I have spent more time standing in front of walls just looking than most people would believe, and it is never wasted time. The wall will tell you what it is made of, how it was built, what went wrong, and what you need to put back — if you know how to ask.

Let me give you a hypothetical to set the scene, because this is how the work actually starts. Suppose you walk up to a two-story brick house from the 1920s. The brick is a soft red clay brick with a lot of character — some color variation, some crazing in the faces, the kind of brick that tells you it was fired in a clamp kiln at lower temperatures than modern brick. The joints on the sheltered side of the house are still mostly intact but soft — you can scrape the surface with a key. On the weather side, the joints are eroded back maybe half an inch, and in a few spots someone has patched in gray cement, and right next to those patches the brick faces are spalling. You haven't mixed anything yet. You already know most of the story.

Start with color, and read it twice — dry and wet. Dry mortar color and wet mortar color are often two different things, and both matter. A lime mortar that looks almost white when it's dry might go to a warm gray-cream when you mist it. The wet

color is the one you want to remember, because your new repointing mortar will spend part of its life wet, and the color match has to survive the rain. I carry a spray bottle for exactly this reason. Mist the joint, let it soak in for a minute, and look. The sand color dominates the wet reading, and the sand color is the hardest thing to fake — if the original sand was a warm tan river sand, your replacement needs to be a warm tan river sand, not whatever the supply house had on the pallet. Write down what you see in plain words: "dry: light gray-white; wet: warm tan with dark speckles." You'll be grateful later.

Next, look at the sand itself. Pick out a loose crumb of the old mortar and break it apart in your hand. What does the aggregate look like? Is it coarse or fine? Are the grains sharp and angular, or rounded like river sand? Is it mostly one size, or a mix from fine to coarse? Are there dark specks, bits of shell, small pebbles, even bits of coal or ash? Old mortars were mixed from local sand, and local sand has a fingerprint. A sharp, well-graded sand — one with a range of particle sizes — makes a mortar that packs tight and weathers well. A rounded, single-size sand makes a softer mortar that erodes faster. You don't need a lab to see this. You need a pocket magnifier and patience. What you're learning is the recipe you'll need to recreate, because the sand in your new mortar needs to behave like the sand in the old one. A coarse old mortar repointed with a fine modern sand will shrink differently, cure differently, and look wrong from the street.

Then look at the joint profile and the tooling marks. This is the mason's handwriting, and on historic buildings it matters because the profile changes how the wall sheds water. Run your eye along the joints. Are they struck — angled so water runs off? Are they flush, cut flush with the brick face? Are they weathered — recessed a little so the brick edges stand proud? Are they tooled with a rounded jointer, or struck flat with a trowel? In some eras and regions you will find grapevine joints, V-joints, penciled joints where the edges were lined with a pencil of mortar. The profile is not decoration, though it is beautiful. A struck or weathered joint throws water away from the wall. A flush joint gives water a place to sit. When you repoint, you put back the profile that was there, because the wall's water management was designed around it. Take photographs, close and at a distance. Sketch the profile in your notebook. Future you, mixing mortar on a Tuesday, will not remember exactly what the joints looked like on that Saturday. The notebook will.

Now the hardness test, and this is where the plain field work comes in. You are going to assess how hard the existing mortar is, and you're going to do it with tools that fit in your pocket. The scale I use is simple and it has served me for decades. Can you scrape material out with your fingernail?

That is a very soft lime mortar — the kind that was made lean, or that has weathered a long time. Can you scrape it with a key or a screwdriver but not your fingernail? That is a typical historic lime mortar in sound condition. Can you scratch it with a knife blade but not a key? That is a stronger lime mortar, maybe a lime with a little early cement in it, common in transitional-era buildings from the late 1800s into the early 1900s. And if your knife barely marks it — if it rings hard and the scratch just skates across the surface — that is a Portland cement mortar, and if it is in the joints of an old soft-brick wall, you have found your hardness mismatch. Your new mortar should never be harder than the mortar you're replacing. That is the whole law in one sentence. You match the hardness, you don't upgrade it.

Here's a second hypothetical, because this one comes up constantly and it trips people up. Imagine a homeowner — completely hypothetical — shows you their 1910 house and says the previous contractor already "fixed" the worst wall with modern mortar, and it looks fine. The joints are crisp and gray and perfect. But you run your fingernail test on the original joints on the other walls and they are soft as chalk. The perfect-looking wall is the problem wall. It looks better and it is worse. This is one of the hardest conversations in restoration work: telling someone that the best-looking repair on their house is the one that's destroying it, and that the fix is to take out the hard mortar and put back something softer. I always explain the cushion principle — the mortar has to be the part that gives. People understand it once you show them the spalling next to the perfect joints. The wall is its own witness.

While you're reading, also note what's happening around the mortar, because the joints are only part of the map. Look at the brick faces for spalling, which points to trapped moisture or a hardness mismatch, as we covered in Chapter 1. Look for efflorescence, the white salt bloom, which tells you water is moving through the wall and carrying salts with it — and where it's heaviest is where the moisture path is strongest. Look at the mortar joints near the ground for soft, crumbly deterioration that might mean rising damp — moisture wicking up from below. Look up high at parapets and chimneys, which take the worst weather and usually need work first. And look for previous repairs: patches, smears, different-colored joints, anything that doesn't match. Old walls are often a patchwork of decades of well-meaning work, and you need to know which repairs helped and which ones hurt before you add your own layer.

If you take samples — and on serious jobs you should — bag them by location and label them like you mean it: wall, height, exposure, condition. A sample that just says "old mortar" in a bag is a mystery, not a sample. Take enough to actually work

with, a few ounces per location, from spots where the mortar is already loose or where you'll be raking anyway. Never gouge sound historic mortar just to get a sample. That defeats the whole purpose of being there.

Let me be straight about the limits of field reading, because honesty is the whole brand here. Everything in this chapter — the color reading, the sand analysis, the scratch test — gets you to a solid, workable match for most houses. But there are cases where the wall is important enough, or the mix is unusual enough, that you want a lab to weigh in. A mortar analysis lab can tell you the original mix proportions, the binder type, and the sand gradation with precision no fingernail test can match. On a designated landmark, a museum, or any building where the stakes are high, sending samples out is the professional move. And as I said in Chapter 1: if the wall is moving, leaning, or cracking in ways that go beyond the joints, you bring in a structural engineer before you bring in a trowel. Reading the mortar tells you what to put back. It doesn't tell you whether the wall can stand. Know which question you're answering.

The discipline of this chapter is simple: the wall gets a full reading before it gets a single grain of new mortar. Color dry and wet, sand character, joint profile, hardness, surrounding conditions, previous repairs — all of it, written down, before you mix. Most of the bad restoration work I've seen in fifty years came from somebody who skipped the reading and went straight to the doing. Don't be that somebody. The map is right there in the joints. Read it first.

Chapter 3: Lime, Explained — Hydrated, Fat, and Hydraulic

Lime is one of the oldest building materials on earth, and it is also one of the most misunderstood by modern masons, because the lime you buy in a bag at the supply house is only one member of a whole family, and the family members do not behave alike. If you're going to work on historic walls, you need to know the family. Get the wrong member and your mortar will fail, sometimes fast and sometimes slow, but it will fail.

It starts with limestone. Limestone is calcium carbonate, and when you heat it in a kiln — a process called calcining — you drive off the carbon dioxide, and what comes out the other side is quicklime, calcium oxide. Quicklime is ferocious stuff. Drop water on it and it slakes violently, steaming and hissing and throwing off enormous heat. The slaking reaction converts the quicklime into calcium hydroxide, and that calcium hydroxide — in one form or another — is the binder in

every lime mortar ever made. The whole family tree grows out of what you do next with that calcium hydroxide.

The first branch is fat lime, also called lime putty, also called non-hydraulic lime. This is calcium hydroxide in its purest traditional form: quicklime slaked with water and then stored wet, under water, for months or years. The longer it sits, the better it gets — the old masons would mature their putty for years, and there are stories of putty pits that were kept going across generations. Lime putty is the softest, most workable, most forgiving mortar binder you can use. Mixed with sand, it makes the classic historic mortar: soft, breathable, slightly flexible, and self-healing over time. But it has a catch, and the catch is how it cures. Fat lime cures by carbonation — it absorbs carbon dioxide from the air and slowly converts back into calcium carbonate, back into limestone. Carbonation is slow. It moves inward from the surface at a pace you can measure in fractions of an inch per year. The outside of a joint carbonates in weeks; the deep interior can take years. And carbonation needs air. In a deep joint, or in damp conditions where air can't reach, a fat-lime mortar can sit soft far longer than you planned. This is why you protect it, why you wait, and why you never judge a fat-lime joint by how it feels on day three.

The second branch is hydrated lime powder — the bagged lime most masons have actually touched. This is quicklime that was slaked at the factory under controlled conditions and dried into a powder. It is chemically the same calcium hydroxide as fat lime, and it is far more convenient — you can store a bag of it, scoop it into a mixer, and go. But convenience has a cost. Factory slaking produces a coarser particle than properly matured putty, and particle size is everything in lime work. Finer particles mean more surface area, better water retention, smoother workability, and a denser, more durable mortar. A good practice that a lot of experienced restoration masons follow is to soak bagged hydrated lime in water — to make it into a putty — and let it mature for at least a few days, and ideally a few weeks, before mixing. You are essentially turning the factory product back toward the traditional product. It is a simple step and it makes a real difference in the working qualities of the mortar. Like fat lime, hydrated lime cures by carbonation, with all the same patience required.

The third branch is natural hydraulic lime, NHL, and this is where the family gets a second chemistry. NHL comes from limestone that naturally contains clay impurities. When that limestone is calcined, the clay reacts with the lime at high temperature to form calcium silicates and aluminates — the same family of compounds that make cement hard. When NHL mortar gets wet, those compounds react with water and harden, the way cement does. This is called a hydraulic set,

and it is fundamentally different from carbonation. A hydraulic set does not need air. It happens underwater, in deep joints, in damp weather. An NHL mortar will set up in hours to days, and then it continues to carbonate over months and years, gaining additional strength and durability from the lime portion. NHL is graded by strength — the common grades are NHL 2, NHL 3.5, and NHL 5, with the numbers indicating the approximate compressive strength. For most historic repointing work on soft brick, NHL 2 or 3.5 is the working range; NHL 5 is strong enough that you need to think carefully before using it on very soft masonry, because now you are back near the hardness-mismatch problem from Chapter 1.

So which lime for which wall? The honest answer is: match what was there, and let the exposure decide. For sheltered joints on an old building — the walls that stay relatively dry and out of the wind — a fat lime or hydrated lime mortar is the authentic and appropriate choice. It is the softest option, it carbonates fine in sheltered conditions, and it most closely resembles what the original masons used. For exposed locations — parapets, chimneys, the windward elevation, anything that takes driving rain — an NHL 2 or 3.5 is the practical choice, because it will set even in damp conditions and it will stand up to weather while staying far softer and more breathable than Portland cement. And for matching a transitional-era wall — late 1800s, early 1900s, the period when masons started adding a little cement to lime — a lime mortar with a small proportion of Portland cement can be the right historical match. But that proportion stays small, and the mortar must still test softer than the brick. The scratch test from Chapter 2 is your referee. Whatever you mix, it never gets harder than the masonry it's serving.

Now the part that separates people who've actually done this from people who've only read about it: the cure. How you treat the mortar after you place it decides whether it succeeds, and lime mortar demands different care than cement mortar. With fat lime and hydrated lime, you are waiting on carbonation, so the joint needs air and it needs time, and it needs protection from drying out too fast. Hot sun and dry wind are the enemies — they suck the water out of the surface before the mortar has structured itself, and you get a weak, dusty joint that never really develops. In hot weather, you mist the joints regularly for days. You hang damp burlap or mist covers. You keep the work shaded when you can. In cold weather, you protect against frost, because a fresh lime joint that freezes before it carbonates is a ruined joint — the ice expands and tears the structure apart from the inside. No lime mortar goes in when freezing temperatures are expected within days. With NHL, you get the hydraulic set as a head start, which makes it more forgiving in damp weather, but you still protect it from rapid drying and from

frost. The rule for all lime work: slow is strong. Every shortcut in the cure is a withdrawal from the mortar's lifespan.

Storage and handling deserve their own plain talk, because lime is not inert and it is not harmless. Quicklime, if you ever handle it in raw form, is caustic and the slaking reaction is violent — eye protection, gloves, and real caution are non-negotiable, and frankly most masons will never need to slake raw quicklime. Lime putty is alkaline and it will burn your skin with prolonged contact — wear gloves, wash up, keep it out of your eyes. Bagged hydrated lime is dusty, and the dust is an irritant — a dust mask when you're pouring bags is basic sense, not paranoia. Store bagged lime dry, because damp bags set into useless lumps. Store putty under water with a lid on it, because putty that dries out crusts over and the crust is waste. And keep lime mortar materials away from cement contamination on the job site — one shovelful of Portland cement accidentally getting into a lime batch changes the whole chemistry. Clean tools, clean mixer, clean habits.

One more plain-spoken note, because I've watched this mistake too many times. There is no single "historic mortar mix" that works on every old building. I will give you proportion ranges later in this book, and they are good ranges, but they are starting points, not scripture. The wall you read in Chapter 2 — the color, the sand, the hardness, the exposure — is what sets your final mix. A sheltered garden wall and an exposed chimney cap on the same property may need different limes, and there is nothing wrong with that. The original builders knew their exposures, and their mortars varied across the building. Your job is to read the map and match the material to the spot, not to find one magic recipe and stamp it everywhere.

I want to close this chapter with where my authority comes from and where it stops, because I make this speech to every crew and I mean it. I am not a chemist. I am not a licensed engineer. I have no letters after my name and I don't want any. What I have is fifty years of hands mixing lime, eyes reading walls, and hands feeling joints cure — decades of seeing what lasts and what fails, in Texas weather, on real buildings. That is the whole of what this book stands on. The chemistry I've described here is the plain-English version of what's happening in the joint, and it is accurate as far as it goes, but the judgment calls — the mix for your wall, in your exposure, on your building — those come from field experience applied to field reading. And where the question is structural, as I keep saying, it goes to a structural engineer. Lime is my craft. Structure is theirs.

Chapter 4: Mixing the Match — Building the Right Mortar for Old Walls

The single biggest mistake I see on historic brick walls is somebody showing up with the same mortar mix they'd use on a brand-new house. Old brick and old mortar are a different animal, and the mortar you put back into that wall has to be built for that wall, not for a job last month. This chapter is about how you build the right mix: reading the old mortar, choosing your materials, and keeping your batches honest across a multi-day job.

Let me start with the ingredient that does most of the talking in a restoration mortar: the sand.

Most of any mortar mix is sand. The binder is just the glue that holds it together. That means the color, the texture, and a good part of the personality of your finished joint come straight from the sand you pick. And here is the thing people get wrong: sand is not sand. The sand from one pit can be pale cream, and the sand from the pit twenty miles down the road can be deep reddish-brown. Around here in Texas, our pit sands run tan to warm brown depending on where they were dug, and every one of them will make a different-looking joint out of the same binder.

So when you are working on an old wall, the local sand pit color is not a small detail. It is the whole ballgame. A gray masonry sand from the big-box supplier will never match an 1890s joint that was mixed with warm creek sand. Your first move is to look at the old joint, really look at it, and then go find a sand that already lives in the same neighborhood of color. You are trying to make the new mortar look like it grew up in that wall, not like it moved in from out of state.

Now, color is only half of what the sand brings. The other half is the gradation, which is just a fancy word for the spread of grain sizes in the pile. Run a handful of sand through your fingers. A good mortar sand has grains from coarse down to fine, like gravel down to powder, so the particles lock together. If your sand is all one size, the mix feels harsh and open, and it does not pack into the joint the same way. You can check this in the field with nothing but a jar: fill it halfway with your sand, add water, shake it hard, and set it down. When it settles, you will see the layers separate out — the coarse stuff on the bottom, the fines on top. It is a crude test, but it will tell you right away whether you are holding a well-graded sand or a single-size washed sand that will fight you on an old wall.

The next skill is learning to read the old joint itself. Before you mix a thing, you need to take a small piece of the old mortar — and I mean a small piece, from mortar that is already loose or falling out, never carved out of a sound joint — and get to know it. Crumble it gently in your hand. Wash a pinch of it in water in a jar and let the sand settle out. Now you can see the old aggregate: the color of the grains, the sizes, whether there is grit in there or it is all fine. Some old Texas mortars have sharp coarse sand you can feel between your fingers. Some are buttery fine. You are not trying to be a laboratory. You are trying to train your eye so that when you mix, you know what you are aiming at.

With that reading in hand, you can talk ratios. Most historic lime mortars I have opened up run somewhere in the neighborhood of one part lime binder to three parts sand by volume. I say neighborhood because the old masons were not carrying measuring cups — they went by feel, and the mix drifted from batch to batch even on the same building. But one-to-three is a sane starting point for a traditional lime mortar. The temptation for a modern mason is to beef up the strength with Portland cement. Do not do it on soft old brick. That is the whole lesson of restoration mortar, and I will say more about it later in this book: the new mortar must be softer and more breathable than the brick, or the brick becomes the weak link. When in doubt, hold the Portland back and trust the lime.

That brings us to the part of the job that separates the craftsman from the hack: trial panels and test joints. Never — and I mean never — mix up a full batch and start repointing a historic wall with an untested mix. Here is how the pros do it. You build a small test panel with the same kind of brick as the wall, or you pick an inconspicuous corner of the actual building — behind the downspout, up under the eave — and you repoint a few feet. Then you walk away. Leave it alone and come back in a week. Lime mortar cures slowly, and the color will shift as it dries and carbonates. What looked perfect on Tuesday can be a shade off the following Tuesday, and you need to know that before you have done three walls. I have seen jobs where the mason skipped the test panel, and by the time the mismatch showed up, half the facade was done. The fix cost more than the whole job. A little patience up front is the cheapest insurance you will ever buy.

Once you have a recipe you are happy with, the job becomes one of discipline: batch consistency across the whole project. Historic restorations are rarely one-day jobs. They run days, sometimes weeks, and if your mix drifts from Monday to Friday, the wall will show it — bands of slightly different tone marching across the facade like a barber pole. The fix is simple but it requires discipline. Measure by volume, every single time. Use the same bucket, the same shovel count, the

same routine. Write the recipe down on paper and tape it to your mixing tub: so many shovels of this sand, so many of lime, this much pigment if you are using any, this much water to a workable feel. Do not eyeball it. The old-timers who mixed by eye had fifty years of muscle memory backing them up, and even they drifted. You have a notebook. Use it.

There are a few more habits that keep your batches consistent. Keep all your sand in one place, from one delivery, and cover it. Sand piles that get rained on change moisture content, which changes your water demand, which changes the mix even if your measurements never moved. If you are blending two sands to hit a tone — which I will get into in the next chapter — blend a whole job's worth of the dry sands up front if you can, so every batch starts from the same blended pile. And mix your mortar the same way every time: same paddle, same mixing time. The feel of the mix is data. If one batch feels richer or leaner than the last, stop and figure out why before you lay another joint.

There is one more piece of batch discipline worth building into your routine: how you actually mix. Whether you are using a hoe in a wheelbarrow or a paddle on a drill, mix the same way, for the same amount of time, every batch. Under-mixed mortar has streaks of dry material and pockets of wet; over-mixed mortar gets overworked and loses body. When a batch feels right, note the mixing time that produced it and repeat it. A kitchen timer costs a few dollars and will do more for your consistency than any fancy additive. Consistency is not a talent. It is a routine.

Now, a word about what we do on our end, because people ask. The Mortar Bucket — the operation folks know at mortarmagic.netlify.app — is our mortar color-matching shop. The craft is exactly what I have been describing in this chapter: taking a sample, reading the old sand and tone, and building a small-batch mortar that belongs in that wall. It is bench work, not wizardry. We do it the same way I have told you to do it: start from the old joint, match the sand, test, cure, compare, adjust. If you ever send a sample out for matching, ask how it was done. If the answer is a catalog number pulled off a shelf, that is a product, not a match. A real match is built against your sample, tested, and proven before it ever goes in your wall.

Before we leave this chapter, let me give you a short field routine you can carry to the next job. First, read the old joint — a loose crumb, washed in a jar, studied with your eyes and your fingers. Second, find a sand in the color family of the old work and check its gradation. Third, build your trial: one part lime to three parts sand as a starting point, laid in a test panel or a hidden corner. Fourth, wait for the cure and read the dried, settled color. Fifth, write the recipe down exactly, and

guard it through the whole job — same materials, same measures, same routine, every batch. That is the craft of mixing the match. The next chapter goes deeper into the fine art of the color itself, where the last five percent of the match is won.

Chapter 5: Color Matching at the Restoration Level

If mixing the mortar is the craft, color matching is the art. Here is the uncomfortable truth about it: a perfect match is a moving target. Mortar does not have one color. It has at least three. It looks one way when it is wet and fresh, another way when it dries, and yet another way after it has aged against the building for a year or five or fifty. The restoration mason's job is to aim at the third color — the aged color — using only the first two as guides. This chapter is how you do that.

Start by understanding what you are looking at. Fresh lime mortar is dark because it is full of water. As it dries, it lightens — sometimes a little, sometimes a lot. A mix that looked like a dead match at noon on installation day can be a shade light by the end of the week, and that is normal. It is not a mistake; it is chemistry and drying. Then time goes to work on it. Sun, rain, dust, and a little airborne grime all push the joint toward a softer, more weathered tone. The old joints you are trying to match have had decades of that seasoning. Your new joints have had days. You will never make brand-new mortar look like fifty-year-old mortar on day one, and anyone who promises you that is selling something. What you can do is get the base tone right and let time close the last gap.

That is why sampling the old joint is the foundation of everything, and it has to be done without destroying what you are trying to save. The rule is simple: take your sample only from mortar that has already failed. If there is a piece of joint that is loose, crumbling, or falling out on its own, that is your sample. You never, ever carve sound mortar out of a historic wall just to get a color read. The whole point of restoration is to disturb as little as possible, and a mason who gouges good joints for samples is doing the building harm. A loose crumb the size of a walnut is plenty. Bag it, label it with the building and the location, and that crumb becomes your reference for the entire job.

With your sample in hand, there are two honest ways to adjust color beyond the sand itself. The first, and the one I prefer, is blending sands. Remember from the last chapter that the sand sets the base tone. If your old joint has a warm, reddish-cast sand and your local sand runs too pale, you can

bring in a second sand — maybe a redder pit sand — and blend the two dry until the blend reads like the old aggregate. Blend big, not batch by batch: mix the full job's worth of dry sands into one pile so every batch draws from the same blend. This is the most natural way to move a color, because you are moving it with the same material the old mason used — aggregate, not paint.

The second way is pigments and tints, and this is where discipline matters more than anywhere else in the job. Mineral pigments — the iron oxides in reds, yellows, browns, and blacks — are colorfast and compatible with lime mortar, and they can close the last gap between a sand blend and the old joint. But here is the law: a little goes a long way. I mean a very little. A pigment dose that is even slightly heavy will overshoot the target and leave you with joints that look like they belong on a different building. The pro's habit is to weigh pigment on a scale, not scoop it by eye, and to record the weight against a fixed batch size — so many grams per so many gallons of mix, or per wheelbarrow, whatever your unit is. Start below what you think you need. You can always add more in the next test batch. You cannot take it out.

There is a thief on every job site, and it steals color judgment: bad light. Sunlight and shadow cheat your eyes in ways you would not believe. The same joint looks warmer in the low sun of late afternoon and colder under an overcast noon sky, and it looks different again under a bright work light. If you judge your match in the wrong light, you will adjust toward a target that does not exist. The working habit is this: make all your color decisions in the same neutral light, at roughly the same time of day, and step back and look at the joint in shadow as well as sun. When you compare your test panel to the old work, stand them side by side and give your eyes a minute. Look, look away, look back. Fresh eyes catch what tired eyes miss.

The light is not the only thing that plays tricks on you. The brick itself cheats your eyes too. A joint reads darker against a pale brick and lighter against a dark brick — the same mortar, two different impressions, depending on its neighbor. This is called simultaneous contrast, and it means you cannot judge a joint floating in isolation. Always read your test panel against brick that looks like the wall, and always compare the old and new joints in the same visual field, side by side. If your panel brick is a different color than the building's brick, your judgment is built on sand. Get the brick close, and the joint will tell you the truth.

It also pays to keep a living sample board on the job. Lay a short run of test joints on a spare piece of board or a brick prism, dated and labeled with the recipe that made them, and keep them through the whole project. When day four's batch

starts looking a little different than day one's, the board gives you something real to check against — not your memory of Tuesday, but Tuesday's actual mortar. At the end of the job, the board becomes part of the file, and if the building needs work five years later, the next mason has your recipe and your actual samples, not just numbers on a page.

Let me give you a hypothetical to tie it together. Picture a hypothetical old courthouse job in a small Texas county seat — not a real job, just a composite of the kind of work that comes up. The old joints are a warm buff, full of local creek sand with a pinkish cast. Your pit sand is paler. You blend in a redder sand until the dry blend reads close. You lay a test panel, and at day one it looks a hair light, which you expected — wet mortar always dries lighter. At day seven you read it again in neutral morning light and it is just a touch pale still. So you add a small weighed dose of yellow-brown oxide to the recipe, lay a second test panel, wait another week, and now the match sits right against the old joints in both sun and shade. That is the whole process: blend, test, cure, read, adjust, test again. There are no shortcuts. There is only the panel and the week.

Now the part people skip, and it is the part that costs the next repair its match: document the final recipe. When the last test panel passes, write down everything. Not from memory — on paper, right then. The sand sources and the blend proportions. The binder-to-sand ratio. The pigment, by weight, per batch unit. The water you mixed to. The date. Tape a copy to your mixing station and keep a copy in your job file. Five years from now, when a window installer chips out three feet of that same wall and someone has to put it back, your notes are the only way the new work has any chance of matching. A recipe that lives in your head is a recipe that dies with your memory of it. Write it down.

One more piece of honesty before I close. Even with perfect technique, your new joints will read a little fresher than the old work for the first year or two. That is not failure. That is new mortar being new mortar. The seasoning will come. If the base tone is right — and I mean truly right, not close-enough right — the weather will do the last bit of blending for you, and a year later the repair will sit quiet in the wall the way good restoration work is supposed to. Loud work shows. Quiet work respects the building. Aim for quiet.

Color matching at this level is slow, and it is worth it. The joints are the lines that draw the face of the building. Get them right, and nobody notices your work at all — which, on a historic wall, is the highest compliment there is.

Chapter 6: The Secretary's Standards, in Plain English

Sooner or later, if you do restoration work, somebody is going to say the words "the Secretary's Standards." It sounds like legal talk, and it scares some contractors off, but it should not. This is just the national guidance the preservation world works under — written by the U.S. Secretary of the Interior's office, used by preservationists, review boards, and grant programs all over the country. Think of it as the bar. If you want your restoration work respected — by a landmarks commission, by a building owner who cares, by the craft itself — this is what you are measured against. And the good news is that when you strip away the formal language, the Standards are mostly common sense that any honest mason can get behind.

Let me give it to you in plain English, the way I would explain it leaning on a tailgate.

First principle: know what you are working on before you touch it. The Standards start with identification and evaluation. That means you figure out the building's age, its materials, and what makes it significant before you start pulling joints. A wall is not just a wall. The brick, the mortar, the bond pattern, the joint profile — those are part of the building's story. The mason who understands what he is looking at does better work than the one who just starts grinding. Walk the building. Read the mortar. Understand the brick. Then pick up your tools.

Second principle: do the least work that gets the job done. This is the heart of the whole thing, and it runs against the way a lot of contractors bid work. The Standards say you do not repoint what is not failing. If a joint is sound — firm, tight, doing its job — you leave it alone. Repointing a whole facade because a quarter of it is deteriorated is not restoration; it is replacement wearing a restoration costume. The right scope is surgical: take out the mortar that has failed, and leave the sound mortar to keep doing its job. This is also where you save your customer money and earn their trust, because you are bidding the work the building actually needs instead of the biggest invoice you could justify.

Third principle, and this is the big one for the trade: the new mortar has to match the old in strength, composition, color, and texture. Read that again, because it is four separate requirements and people only remember the color. Strength means the new mortar must be no harder than the historic mortar was — and on most old buildings, that means softer than what modern masons are used to. Composition means the ingredients have to be in the same family: a lime-based

mortar where the old work was lime-based. Color and texture, you already know from the last two chapters. The reason for the strength rule is simple physics, and the Standards take it seriously: mortar is supposed to be the sacrificial part of the wall. If your new mortar is harder than the old brick, the brick takes the damage instead. You have traded a cheap, replaceable joint for ruined masonry units. That is a bad trade, and the Standards exist partly to stop people from making it.

Fourth principle: duplicate the old joint. The new joints should match the old ones in width and profile. If the historic joint was a narrow struck joint, you do not come back with a wide concave joint and call it close enough. The width and the profile are part of how the wall sheds water and part of how it looks. Changing them changes the building. Take a joint profile gauge to the old work — or at minimum, study the surviving sound joints with your eyes — and make your new joints read the same.

Fifth: prepare the joint properly. The Standards call for sound preparation, and in the field that means raking out the failed mortar to a proper depth, getting back to sound material, and cleaning the joint so the new mortar can bond. The old rule of thumb is to rake to a depth of about two to two-and-a-half times the joint width, or until you hit firm mortar, whichever comes first. Clean the joint of dust and loose debris. Dampen the brick before you pack in the new mortar so the thirsty old units do not suck the water out of your mix and kill the bond. None of this is glamorous. It is just the unglamorous work that makes the pretty work last.

Sixth: use the gentlest cleaning that works. The Standards are blunt about this, and I am with them: do not sandblast or high-pressure-blast historic masonry. Abrasive cleaning chews up the face of the brick and the surface of the stone, and what looks clean on Tuesday can be a spalling mess in three years. If the wall needs cleaning, you test the gentlest method first — water, a soft brush, mild methods — and you stop as soon as it is clean enough. Cleaning is not restoration. Over-cleaning is damage.

There is a couple more ideas woven through the Standards that are worth carrying with you. One is that maintenance comes first: a building that is kept dry, with its gutters working and its caps in place, needs far less repointing than a neglected one. The best restoration is the repair you never have to do because the water never got in. The other is reversibility in spirit — do work that a future mason can undo without harming the original fabric. The lime mortar approach already leans this way, because a softer mortar can be removed later without destroying the brick. Portland-heavy work on soft brick fails that test badly.

One more habit the Standards reward, even though they do not headline it: document the work. Photograph the wall before you touch it, during the raking, and after the pointing. Keep your mortar recipe in the job file — binder, sand sources, ratios, pigment weights, joint profile, the works. On tax-credit and grant projects, this record is often required. On every other project, it is still the mark of a professional. A mason who can show the owner exactly what went into their wall, and why, is a mason who gets trusted with the next old building on the street. Your documentation is your signature on the work.

Now, a few practical notes on how this plays out in the real world. If you are bidding a job on a building in a historic district, the local preservation commission probably works off these Standards, and your submittal — your mortar recipe, your joint profile, your scope — will get judged against them. Speaking the language of the Standards in your proposal is not showing off. It is telling the reviewer you know the bar and you intend to clear it. And if a job involves structural questions — sagging lintels, bowed walls, anything where the masonry is moving or the loads have changed — that is the moment to bring in a structural engineer. The Standards describe the restoration craft; they are not a substitute for engineering judgment, and no honest mason should pretend otherwise.

Let me also say what the Standards are not. They are not a building code, and they are not a law that follows you onto every job. Nobody is going to show up on a private farmhouse job and fine you for a bad mortar choice. They are guidance — but they are the national guidance, the shared language of everyone in this country who takes old buildings seriously. When a grants program, a tax-credit project, or a landmarks board says "work to the Standards," this is what they mean. And even where nobody requires it, working to this bar is how you build the kind of reputation that brings the good restoration jobs to your door. Owners of historic buildings talk to each other. The mason who matches strength and composition, who leaves sound joints alone, who duplicates the old profile — that mason gets the next call.

Here is the whole chapter in one paragraph you can carry in your head. Learn the building first. Touch only what is failing. Match the old mortar in strength, composition, color, and texture — with the new mortar softer than the brick. Duplicate the width and profile of the old joints. Prepare joints properly and clean gently. Maintain the building so water never wins. And when structure is in question, call the engineer.

That is the Secretary's Standards in plain English. It is the bar the preservation world works under, and now you know

where it sits. Clear it, and your restoration work will stand up to anybody's inspection — including your own, ten years later, when you drive past that building and the joints are still sitting quiet in the wall.

Chapter 7: Raking and Grinding Without Chewing the Brick

Every repointing job lives or dies before a single ounce of new mortar goes into the joint. What happens in the prep stage decides whether the wall comes out looking like it was lovingly restored or like it got mugged by a power tool. I have torn out and repointed more linear feet of brick joints than most people will ever look at, and I will tell you the plain truth: raking the old mortar out is the slowest, dustiest, least glamorous part of this work — and it is the part that separates a craftsman from a hack.

Old lime mortar that has reached the end of its life is a gift in one way: it is soft. You can rake it out with a hand tool. A raking hook, a mason's joint raker, even a stiff screwdriver in a pinch — the failed lime mortar gives up and crumbles out. That softness is exactly why the building survived. The mortar was supposed to be the sacrificial layer, softer than the brick, so it takes the abuse from weather while the brick units stay sound. But that same softness is what makes power tools so dangerous on a historic wall. The grinder does not know the difference between soft old mortar and soft old brick. It does not care. It cuts whatever you point it at, and it cuts brick faster than it cuts crumbly mortar if you lean on it wrong.

I have walked up to houses where somebody — and I am being kind calling them somebody — ran a grinder down every joint on a 1910 facade and turned a wall of soft red sand-struck brick into a checkerboard of cut scars and overground arrises. The arris is the sharp edge where the face of the brick meets the joint. On a crisp old brick, that edge is clean and square. One slip with a grinder, and the edge is rounded, gouged, or cut clean off — and brick does not heal. You cannot patch a ground-off brick face back on. It is permanent. The wall is scarred forever, and every neighbor with eyes can see exactly what happened. A grinder scar on brick is like a tattoo you got in a parking lot at midnight: it is there for life, and it tells everybody you were not thinking straight.

So here is my rule, and it has never failed me: hand-rake first, and use the grinder only where the mortar forces you to. If the joint gives up under a raking hook, you are done — keep the grinder in the truck. The grinder earns its keep on the jobs where somebody in the past went in with Portland

cement mortar, which sets up hard as a sidewalk and will not budge under a hand tool. Then you need a grinder, and you need to run it like a surgeon, not a demolition crew.

If you must grind, set the blade depth shallow and make a single pass right down the center of the joint. Do not try to hog the whole width out in one pass — that is how you wander into the brick. I use a tuck-pointing blade, which is thinner than a standard masonry blade, so it fits the joint instead of riding the arrises. Two light passes down the center of the joint, then come back with the raking hook and crumble the sidewalls out by hand. That technique gives you a clean, square joint with crisp arrises and zero scars. It is slower. It is dustier per square foot. It is also the difference between restoration and damage, and on an old wall, you do not get a second chance.

Depth is the next thing that matters, and there is a real guideline for it, not a guess. Rake the joint out to a depth of about two to two-and-a-half times the joint width. On a standard half-inch joint, that means you want roughly an inch to an inch and a quarter of depth. Why? Because the new mortar needs enough body in the joint to bond, compact, and shed water. A shallow scrape — a quarter inch of new mortar sitting on top of the old — is a skim coat. It will pop, it will curl, and it will fail within a season or two, especially in Texas where heat and wind work every weak spot like a pry bar. On the other hand, raking too deep is its own problem. Past two and a half times the joint width, you start disturbing the bond of the brick units themselves and opening up the wall to more weather exposure than it needs while the work is in progress. Measure it. A piece of tape on your raking hook at the target depth works fine. This is not a place for eyeballing and hoping.

Keep your arrises crisp through the whole process. The arris is what makes the joint read as a clean line on the wall instead of a ragged trench. When you are raking by hand, the tool rides the center of the joint and the arris never gets touched. When you are grinding, the thin blade centered in the joint never touches the arris either — until you drift. Watch the arris like it is the edge of a knife blade you are trying not to cut yourself on. That is the level of attention it takes. If you are rushing, you are drifting, and if you are drifting, you are scarring brick.

Dust control and safety are not optional on this work — they are the job, full stop. Grinding mortar, even old lime mortar, puts fine particulate into the air that has no business in your lungs. A respirator with P100 filters is the minimum when the grinder is running. Not a paper dust mask from the bargain bin — a real respirator that seals to your face. Safety glasses that seal, not the kind with the big open sides. Hearing

protection, because a grinder running an hour straight is doing damage you will not notice until years later. And gloves, because tuck-pointing blades and raking hooks are sharp and your hands are going to be on them all day.

Think about dust control for the property too. If this is somebody's home — and it usually is — the grinder dust gets everywhere: on the plants, in the window tracks, on the patio furniture, on the cars in the driveway. I set up drop cloths over plantings, tape off window and door openings, and I keep the vacuum running near the cut on big runs. The customer notices how you treat their property during prep. A crew that controls its dust looks like it knows what it is doing. A crew that leaves a grey film over the whole yard looks like a problem.

Sequencing matters more than most people think. Rake out a section, point that section, move on. Do not rake out an entire facade and leave the wall standing half-open for a week while you work your way across. An open wall is a vulnerable wall. Rain gets in, wind-driven dust gets in, the exposed bedding surfaces start weathering. On a historic wall, the mortar you leave exposed at the back of the joint is the last line of defense, and the longer it sits open, the more it degrades. I work in sections sized to what I can point in a day or two. Rake in the morning, point in the afternoon. The wall is never left sitting open longer than it has to be, and I can walk away at the end of every day knowing the section I opened is closed back up and weather-tight.

Here is a hypothetical composite to make the point — not a real customer, just the pattern I have seen play out more times than I can count. Imagine a 1925 bungalow, soft handmade brick, original lime mortar. The joints are crumbly at the surface, maybe a quarter inch deep. A contractor bids it cheap, shows up with a crew of grinders, and in two days every joint on the house is ground out to a half inch wide — wider than the original joint, because the blade chewed the arrises on every pass. The brick faces are scarred up and down the facade. Then the new mortar goes in — modern Type N, hard as a rock — and it looks fine for about a year. Then the Texas summer starts cycling, the hard mortar expands and contracts against the soft brick, the scars catch and hold water, and by the second year the brick faces are spalling where the grinder damaged them. The cheap bid just cost that homeowner the wall. All of it was avoidable in the prep stage. A week of hand raking, the right depth, the arrises left alone, and the original soft brick would still be standing there untouched for another century.

That is what this chapter comes down to. The prep stage is where you either respect the wall or you ruin it, and the wall cannot tell you which one you chose until it is too late.

Hand-rake what you can. Grind only what forces you to, and grind it like a surgeon. Cut to the right depth, every joint. Keep the arrises crisp. Control your dust, wear your respirator, and never leave a wall half-open. Do those things, and when the new mortar goes in, it goes into a joint that was prepared right — which is the only kind of joint worth pointing.

Chapter 8: Striking the Joint — Tooling That Matches the Old Work

Tooled joints are a fingerprint. Walk up to any historic brick wall and look at the mortar joints, really look at them, and you are reading the signature of the mason who laid that wall — what tool he used, how he held it, how far he pushed it, even what time of day he got to that course. When you repoint a historic wall, your job is not to leave your own signature. Your job is to forge his. The new joint has to look like the old joint, and the only way to do that is to read the old profile and duplicate it with honest craft.

Start by reading the wall. There are five classic joint profiles you will meet on Texas historic work, and each one asks for a different tool and a different hand.

The concave joint is the workhorse of twentieth-century masonry — a smooth, shallow curve pressed into the joint with a round jointer. It sheds water well, it is easy to keep consistent, and you see it everywhere from the 1910s onward. Tool it with a concave jointer the same width as the joint, steady pressure, one clean pass.

The weathered joint slopes the mortar back from the bottom arris to the top, shedding water off the face. You see it on older work and on quality restorations. Tool it with a flat striking tool held at the angle the original mason used — and that angle matters. Get the slope backward and you are funneling water into the wall instead of off it.

The struck joint is the weathered joint's mirror image — raked at the top, flush at the bottom — and honestly it is the weaker profile for weather because it catches water. But if that is what the original mason struck, that is what you strike. You do not get to "improve" a historic wall by changing the profile. Consistency with the original work is the whole job.

The flush joint is exactly what it sounds like — mortar struck flush with the brick face, usually with a trowel or a flat tool. Common on very old work and on walls that were meant to be

plastered or whitewashed. The trick with a flush joint is a light hand: overwork it and you smear mortar across the brick faces, and that smear does not come off clean once it sets.

The grapevine joint is the old-timer's signature — a narrow concave groove struck right down the center of the joint with a special grapevine jointer, leaving a little raised bead of mortar on either side. You see it on nineteenth-century and turn-of-the-century work in Texas, and when you do, you are looking at real craft. A grapevine jointer is a cheap tool. Buy the right one for the joint width and practice on a mock-up before you touch the wall.

The order of operations on the wall matters as much as the profile. Point the joint first — pack the mortar in, compact it, fill it full — then wait for the timing window before you tool. And that timing window is everything.

The window is thumbprint-hard. Push your thumb into the mortar in the joint. If it leaves a wet smear and sticks to your skin, it is too early — tooling now drags the mortar, smears it, and pulls fines to the surface in a way that weakens the joint. If your thumb barely dents it and the mortar crumbles or flakes at the edge, it is too late — tooling now will not compact anything, it will just scratch a dead surface and can crack the joint away from the arris. The window is in between: your thumb leaves a clean print, the mortar dents and holds its shape, it feels firm but workable. That is the moment. On a Texas summer day, that window can be twenty minutes. In cool, still weather, it can be an hour or more. You do not watch the clock — you watch the mortar. Touch it, read it, and tool when it tells you it is ready.

Tooling does two things at once, and both matter. First, it shapes the profile — the fingerprint. Second, and just as important, it compacts the mortar in the joint. Compaction is what makes the joint weather-resistant. Loose, fluffy mortar in a joint is full of tiny voids that hold water, and water in a joint in Texas is an invitation to freeze damage in January and efflorescence year-round. A properly compacted joint — mortar pressed firm and dense by the tooling stroke — sheds water off the surface instead of drinking it in. This is why tooling is not cosmetic. It is the waterproofing of the joint. An untooled joint, even one filled with the right mortar, is a weaker joint. Tool every joint, and tool it with real pressure.

Brushing and finishing come after tooling, and the rule is: brush, do not smear. Once the joint is tooled, I take a soft brush and whisk the loose crumbs and fins off the brick faces with a light flicking motion — brushing across the joint, not along it, so I am not dragging mortar over the brick. The brush should be soft. A stiff brush on fresh mortar scours the joint and streaks the brick. And timing matters here too:

brush when the mortar is still green enough that crumbs come off easy, not after it has set up and bonded to the brick face. If you are seeing mortar smearing across the brick and staining the faces, you are either tooling too early, brushing too hard, or both. Back off, let the wall tell you when it is ready, and use a lighter hand.

Here is something that surprises a lot of people: tooling changes the cured color of the joint. It is not your imagination, and it is not a defect. Tooling brings the finer material — the lime and the fine sand — to the surface of the joint, and that fine surface cures lighter than the body of the mortar. A joint that looks like a perfect match when you strike it can dry a shade lighter, and a joint you strike a second time or overwork will cure lighter still. Plan for it. The practical move is to make a test panel — a few feet of the actual wall, with the actual mortar, tooled exactly the way you plan to tool the whole job — and let it cure for a week or more before you commit to the color. Judge the match in full daylight and in shade, wet and dry, because a cured joint changes with the light and the weather. If your test panel cures lighter than the original, you know the mortar mix needs to go a touch darker, or the tooling needs a lighter hand, before you do the other two thousand square feet. Every restoration mason I respect tests first. The ones who do not are the ones explaining a color mismatch to a homeowner after the whole wall is done.

One more note on matching the old work, and this one is about restraint. When you are repointing, you will find joints the original mason did sloppy — a wavy line here, a joint that is a little proud there, a grapevine that wanders off the course. Your instinct will be to fix it, to make your work straighter and cleaner than his. Resist that instinct. The wall's character is in those imperfections. A perfectly uniform joint line on a 1905 wall looks wrong — it looks like new work pasted onto old brick, which is exactly what the purists will call it. Duplicate the profile faithfully, keep your courses level and your joints consistent, but let the wall keep its honest roughness. You are matching the old work, not auditioning to replace the original mason. He knew what he was doing. Follow his lead.

Now a hypothetical example — a composite of jobs I have seen, not a real customer. Picture a 1915 commercial building downtown, grapevine joints, soft brick, original lime mortar mostly sound but failed at the top two courses where the parapet takes the weather. The right move is surgical: rake those failed joints by hand, point them with a lime mortar matched to the original, strike the grapevine profile with the right jointer, tool at thumbprint-hard, brush it off light, and walk away. The top of the wall looks like the rest of the wall again. What I have seen instead: a crew that ground every joint on the whole building, pointed it with hard modern

mortar, and tooled everything concave because that was the jointer they had in the truck. The parapet is now hard, grey, concave, and uniform — and it looks like a different building grafted onto the top of an old one. Two different joints, two different mortars, two different tools. The wall tells two stories now, and one of them is a mistake. All of that was a tooling decision. The tool you choose and the moment you strike are the visible half of repointing — everything the eye will ever see. Read the old profile, match it with the right tool, hit the timing window, compact it tight, and test your color before you commit. The original mason left his fingerprint in those joints a century ago. Your job is to press yours right on top of it so cleanly that nobody can tell where his work ends and yours begins.

Chapter 9: Curing in Texas Weather

Here is the part nobody tells you when you first learn to repoint with lime mortar: the pointing is only half the job. The other half is what happens after you walk away from the wall — the curing. And curing lime mortar in Texas weather is like trying to raise a garden in a wind tunnel with somebody randomly flipping the thermostat. Lime mortar needs moisture and time. Texas gives you heat, wind, and freeze snaps instead. This chapter is about how you win that fight anyway, from fifty years of hard-won field judgment — not lab theory, just what actually works on a wall in July and in January.

First, understand what is happening inside the joint. Lime mortar cures by carbonation — the lime in the mortar slowly absorbs carbon dioxide from the air and hardens over weeks and months. This is not like modern cement mortar, which sets by hydration in hours. Lime needs to stay damp enough for the chemistry to keep working, and it needs time — real time, measured in weeks, not days. If the joint dries out too fast, the carbonation stalls and the mortar never reaches its full strength. It stays soft, chalky, and vulnerable. If it freezes before it has carbonated enough, the water inside it expands and the joint can blow apart from the inside. So your entire curing job comes down to two things: keep it damp, and protect it from extremes. That is the whole game.

In Texas summer, the enemy is evaporation. A hundred-degree afternoon with a twenty-mile-an-hour wind will pull the moisture out of a fresh joint in hours. You have to put the moisture back. The method is misting — a fine mist from a garden sprayer or a misting nozzle on a hose, light enough that you are wetting the wall, not washing the mortar out of the joints. A heavy stream will erode a green joint and

leave you with a sandy, pitted surface. Mist lightly, mist often. On a brutal July day, I mist a fresh wall every couple of hours through the heat of the day — morning, midday, late afternoon — and I keep it up for at least three to five days, longer on deep joints. The wall should stay visibly damp, not dripping wet. You are aiming for the look of a wall after a light rain, and you are holding it there for days.

Damp burlap is the old-timer's secret weapon, and it still works better than anything. Hang damp burlap over the fresh work — draped, not touching tight — and it holds a humid microclimate against the wall while it shields the joints from direct sun and wind. Wet the burlap down in the morning and again in the afternoon, and the wall underneath stays in the damp, shaded conditions lime mortar loves. On a big facade, I will tent sections with burlap or shade cloth rigged on scaffolding. It looks like overkill to a homeowner the first time they see it. Then they see the joints cure up hard and tight while the neighbor's quick-cured job is chalking and dusting, and they understand.

Work sequencing around the weather is field judgment, pure and simple. Do not start a big pointing run the day before a forecasted heat wave if you can help it — if the forecast says one hundred and five and windy for three days straight, you are going to be fighting evaporation every hour, and you are better off waiting for a milder stretch. I watch the forecast like a farmer. A stretch of eighties with overnight lows in the sixties and a little humidity is pointing weather — that is when I want to be on the wall. When the only window I have is brutal heat, I shift my hours: point early in the morning, get the work in while it is cool, mist through the afternoon, and let the burlap do the heavy lifting.

Cold snaps are the other Texas specialty, and they are arguably more dangerous than heat. Texas will give you a week in the sixties and then drop into the twenties overnight, and a fresh lime joint caught by that swing is in real trouble. Lime mortar that has not carbonated enough cannot take a hard freeze — the free water inside the joint freezes, expands, and cracks the mortar from within. The rule I work by: fresh lime pointing needs protection from freezing temperatures for a minimum of four to six weeks after placement, and honestly, the longer the better. If a freeze is coming and the work is fresh, tent the wall and get heat under the tent — safely, with proper heaters, never an open flame near burlap or scaffolding. If you cannot protect it, do not point it. I have told homeowners exactly that: "We wait. The wall can wait. A blown joint cannot un-blow." Sometimes the most professional thing you can do is park the job until the weather turns.

How long before a joint can take rain or a freeze on its own? There is no single number, because it depends on the mortar,

the joint depth, the exposure, and the weather since placement — but I can give you working guidelines from the field. A lime joint that has been kept damp and protected for four weeks will take a normal rain without damage. A hard driving rain before two weeks, on a joint that was allowed to dry out — that is how you get erosion and sanding. As for freezing: I want a solid six weeks of good curing weather before I trust a fresh joint to a hard freeze unprotected, and if the work went in late in the fall, I would rather tent it through the first freeze than trust the calendar. These are judgment calls, not lab numbers. The wall, the mix, and the weather you actually got all factor in. When in doubt, protect it longer. Caution is free. Rebuilding blown joints is not.

One more field note, because Texas will also hand you the opposite problem: winter work where the mortar itself will not cooperate. Lime mortar mixed and placed when the air is below about forty degrees will barely carbonate at all — the chemistry slows to a crawl, and water sitting in a fresh joint overnight can freeze even if the daytime high looked safe. If you must work in cold weather, mix with warm — not hot — water, keep your sand and lime stored out of the wind and off the cold ground, and never let a batch sit around going cold before it goes in the wall. Small batches, steady pace, and get the tenting and heat up the same day you point. The material will tell you when it is too cold: it goes stiff, it will not compact right, and the joint finishes rough no matter what you do. That is the wall telling you to stop. Listen to it.

So what does rushed curing look like a year later? I can spot it from the street. The joints are dusty — you can rub your finger across them and come away with powder. The surface sands and pits, little craters where the weak mortar has washed out. In bad cases, the mortar has shrunk back from the arris, leaving a gap that catches water and starts the whole cycle of damage over again. The color is often chalky and uneven. And here is the cruel part: it looks fine at first. Rushed curing does not announce itself at the final walkthrough. It shows up six months, a year later, when the Texas weather has done its work on joints that never got their chance to cure. The homeowner calls, upset, and the contractor is long gone or shrugs. All of it — every bit of it — was preventable in the first week after pointing, with a hose, some burlap, and the patience to do it right.

Let me give you a hypothetical to close this out — a composite, not a real customer. Two identical 1920s duplexes on the same street, same brick, same failed mortar, repointed the same month by two different crews. Crew one points the walls, mists them for five days, hangs damp burlap on the sun side, tents the north wall when a blue norther drops the temperature into the twenties in week three, and does not release the job until the joints have had six good weeks. Crew

two points the walls, packs up the same afternoon, and tells the homeowner the mortar "sets up on its own." A year later, crew one's joints are hard, tight, and weathering exactly like the originals. Crew two's joints are powdery, sanding out at the surface, and the homeowner is already getting bids to have it done over. Same brick. Same mortar. The only difference is what happened after the pointing was finished. Curing was the whole difference.

That is the lesson of this chapter, and it is the least technical and most important one in the book. The mix matters. The prep matters. The tooling matters. But none of it survives bad curing. Lime mortar is patient material — it will give you a joint that lasts a century if you give it moisture and time. Texas weather is not patient. So you have to be the patient one. Mist the wall. Hang the burlap. Watch the forecast like it is your money on the line — because it is, it is the homeowner's money, and they trusted you with their wall. Protect the fresh work from the freeze. Give it the weeks it needs. Do that, and the joint you pointed will outlast all of us. Rush it, and you will be back — or somebody else will, fixing what should have been right the first time.

Chapter 10: Soft Brick, Stone, and Adobe — Special Cases

Most repointing work happens on ordinary brick, and ordinary rules cover it. But every mason with enough years behind him runs into the exceptions — the materials that don't behave like the textbook says they should. When the unit is weaker than the joint, the rules change completely. This chapter is about those special cases: soft brick, stone, and adobe. Each one has its own handling rules, its own dangers, and its own point of no return. The examples here are hypothetical composites from field experience, not reports about any real customer or real building.

Let's start with soft brick. Sand-molded brick, handmade brick, early machine-made brick from before about 1900 — these units were fired at lower temperatures than modern brick. They are softer, more porous, and far more absorbent. A brick that soaks up water like a sponge has a face that can be cut away with a fingernail in bad cases. The joint in front of that brick must be the softest mortar you can justify, because the brick itself has no strength to spare.

The rule with soft brick is simple to say and hard to overstate: the mortar must always be weaker than the brick. If the brick is soft, the mortar goes softer still. On the worst handmades I will run a pure lime-and-sand mix with no Portland at all, because even a splash of Portland in the mix can make a joint

harder than the brick it's supposed to protect. The mortar is the sacrificial layer. It is supposed to wear away and be replaced. The brick is supposed to stay.

Joint preparation on soft brick needs a lighter hand. The grinder that works fine on modern hard brick can chew the face off a sand-molded unit in one slip. I do my raking out with hand tools on soft brick — a rake, a cold chisel, a patient hand. It takes longer. It costs more. It is the only honest way. The point of no return with soft brick is the moment you decide the joint needs a harder mortar for durability. There is no harder mortar that is compatible with soft brick. Durability here comes from softness, from a joint that moves and breathes with the unit. The man who puts a hard mortar against soft brick has signed the brick's death warrant, and the damage shows up five to ten years later as spalled faces and hollow walls.

Painted brick deserves its own conversation, because almost every historic building in Texas has been painted at some point. Paint on brick is a judgment call, and the judgment is: is the paint causing harm, or is it the only thing holding the wall together?

Here is what happens with paint. Old oil-based paints and modern latex paints trap moisture behind them to varying degrees. If the wall is getting wet from behind — no flashing, a leaking gutter, grade sloping toward the wall — the paint blisters and peels, and the moisture cycling under the paint face destroys the brick surface. In that case the paint is a symptom of a water problem, and the water problem has to be fixed regardless of what you do with the paint.

Paint removal is where the point of no return lives. Chemical strippers on historic brick are risky business. They can drive paint deeper into the pore structure, and they can leave residues that interfere with mortar bond later. Pressure washing will strip paint off a soft brick and take the face of the brick with it. Abrasive blasting is even worse. The gentlest approaches — hand scraping, low-pressure steam, careful chemical poulticing — are slow and expensive, and sometimes they still leave you with a brick that is cleaner but weaker than when you started.

My field rule: if the paint is sound and the wall is dry, leave it alone. Sound paint that is not trapping active moisture is protecting the brick underneath it, and removing it exposes a face that may not be beautiful and may not survive exposure. If the paint is failing, fix the water problem first, then evaluate. And if the client wants the paint gone for cosmetic reasons, be honest with them: removal on historic brick is a gamble, the original face is probably not under there intact, and the cost of doing it safely is high. Some buildings look

better painted than the owner imagines they will stripped. That is an honest conversation worth having.

Rubble stone and large stone joints are a different discipline. Stone does not behave like brick. It is heavier, it moves differently, and the joints are often enormous — two, three, four inches of mortar between irregular stones. The good news is that stone is usually harder than any mortar you will put next to it, so the compatibility worry runs the other direction from soft brick: the mortar is still the sacrificial layer, but the stone will survive your mistakes better than the brick would.

The temptation with stone is to pump a big fat joint full of hard mortar and call it structural. The mortar in a stone wall is not glue. A rubble wall stands because of the stones, the gravity, and the shape of the stones interlocking. The mortar fills the gaps and keeps water out of them. It sheds water; it does not hold the building up. When you repoint stone, match the old mortar's character — almost always a lime-rich mix — and resist the urge to make the joints harder than they were. A hard, rigid mortar in a wide stone joint cracks at the first season of thermal movement, and then water gets into the crack, and then you are back in five years fixing what the last man's hard mortar broke.

Large joints also need to be filled in lifts, not in one pour. A three-inch joint filled in a single application shrinks back from the stone as it dries, and you get a hairline gap along the stone face that funnels water straight into the wall. Fill in passes. Let each pass firm up. The finished joint should be tooled to match the original profile — and the original profile on old stonework is often a rough, hand-struck joint, not the crisp uniform ribbon a modern mason wants to leave. Match what was there. The wall had a voice before you arrived; your job is to let it keep speaking.

Adobe and unfired units are the far edge of special cases, and they come with a warning: adobe is not masonry in the structural sense that brick is. Sun-dried mud brick has almost no compressive strength by modern standards, no water resistance, and a surface that dissolves under a garden hose. Repointing adobe with anything harder than mud is a mistake, and repointing adobe with lime mortar is only appropriate in specific situations where the wall is protected from direct water.

The honest truth about adobe is that most of what it needs is not mortar at all — it is a roof that doesn't leak, a foundation that doesn't wick moisture up into the wall base, and a surface that sheds water. When adobe does need joint work, the repair material is mud — stabilized earth, sometimes with a small lime addition — and it goes in by hand, slowly, with

full understanding that you are doing maintenance on a material that will always need maintenance. Any contractor who proposes a hard mortar or a waterproof coating on adobe does not understand the material. Walk away from that bid, and advise the building owner to do the same.

The thread through all of these special cases is the same one that runs through the whole book: the mortar serves the masonry, never the reverse. The softest unit sets the ceiling for mortar hardness. The original material tells you what it wants. Your job is to read it, respect it, and do work that will be invisible in fifty years. The moment you find yourself fighting the material — forcing a hard mortar into a soft wall, blasting paint off a fragile face, pouring strength into a stone joint that needs flexibility — stop. The material is telling you something. Fifty years of this work has taught me that the wall is almost always right.

One more special case deserves mention before we close: the wall that is already a composite of past repairs. Almost no historic building reaches you untouched. You will find walls where a previous mason — maybe forty years ago, maybe ten — did partial repointing with a hard mortar, or smeared a parging coat over failing brick, or tucked a modern patch into an old wall. These layered walls are the hardest to read, because you are not looking at the original construction; you are looking at the original construction plus every decision anyone ever made about it.

The handling rule for composite walls is to identify what is original, what is later, and what is failing because of the later work. Often the later work is the problem: the hard repointing that is spalling the brick around it, the parging coat that trapped moisture and is now delaminating in sheets. The instinct is to remove everything that is not original and start clean. Resist the whole of that instinct. Some later work, if it is sound and compatible, can stay. The question is not "is it original" but "is it harming the wall." Remove what is harming the wall. Leave what is not. And document the layers as you find them, because the next mason will want to know what you knew.

Salt is the invisible actor in all of these special cases. Efflorescence — the white bloom on the surface — is salt being carried out of the wall by moisture and deposited on the face as the water evaporates. On soft brick and adobe, salt crystallization just beneath the surface can destroy a face faster than weather alone. If you see heavy efflorescence on a historic wall, the wall is telling you two things: water is moving through it in quantity, and the source of that water has to be found. Repointing over active salt without addressing the moisture is painting over rust. The salt will keep coming, and it will take your new joints with it.

Desalination treatments exist for severe cases, but they are specialist work — slow, expensive, and not guaranteed. For most walls, the honest fix is the boring one: stop the water, let the wall dry, and let the salt exhaust itself over time.

The final word on special cases is humility. The ordinary brick wall forgives a lot. These materials do not. When you are unsure about a soft brick or a stone joint or an adobe wall, the most professional thing you can do is slow down, do more test work, and ask someone who has seen it before. There is no shame in that. The shame is in the mason who was sure and was wrong, because on these materials, wrong is permanent.

Chapter 11: The Business of Historic Repointing

There comes a point in every tradesman's life when he realizes the craft is only half the job. The other half is the business of the craft — how you price it, how you explain it, how you stand behind it. Historic repointing is some of the most satisfying work in masonry, and it is also some of the easiest work to price wrong. This chapter is business advice from fifty years in the trade. It is field wisdom, not financial advice and not legal advice. For contracts and legal questions, talk to a lawyer in your state. For your books, talk to an accountant. What follows is what I have learned about the business of restoration work.

The first rule of pricing historic repointing: price it by skill and time, not by the square-foot race to the bottom.

The square-foot price is the death of good work. When a contractor prices repointing at a flat rate per square foot, he is assuming every square foot takes the same time, requires the same skill, and presents the same risk. On historic work that is never true. One wall is sound lime mortar raking out clean with a hand tool; the next wall is soft brick that has to be worked by hand, joint by joint, with every face at risk. One building has easy scaffold access on a parking lot; the next is three stories over a rose garden on a slope. A square-foot price averages all of that into a number that is too low for the hard walls and too high for the easy ones, and the contractor who lives by it learns to rush the hard walls to make the number work. That is exactly how historic buildings get ruined.

Price by time and skill instead. Estimate the hours honestly — the raking hours, the mixing hours, the pointing hours, the protection and cleanup hours — and multiply by a rate that reflects the fact that this is specialist work. A mason who can read an old wall, match a lime mortar, and point a joint that

will last another century is not performing the same service as a crew slapping a hard mortar over a parking lot. The price should say so. The customer who hires you for historic work is buying fifty years of judgment. Charge for the judgment.

That leads to the second rule: educate the client until they understand what they are paying for and why it takes the time it takes.

Most homeowners have no idea what repointing actually involves. They picture a man with a trowel smearing mortar on a wall. They do not picture the week of joint preparation, the mortar analysis, the test panels, the curing schedule, the weather watching. They hear your price and they hear the other guy's price, and the other guy is half your number, and they cannot see the difference because nobody has shown it to them.

So show it to them. Walk the wall with the client. Point out the failing joints and explain what caused them. Explain why the old mortar failed and why the new mortar has to match it. Explain the curing process and why the work takes weeks instead of days. Show them a test panel. When a client understands the work, two things happen: the honest price starts to make sense, and the cheap price starts to look dangerous. An educated client is your best business partner. An uneducated client choosing on price alone is a future dispute waiting to happen.

This is selling quality and longevity over speed, and it has to be done honestly. Never promise that lime work is fast. Never promise that it is cheap. Promise that it is right, that it respects the building, and that it will last. The pitch is not that you are the cheapest mason in town. The pitch is that the building gets one proper repointing in a generation, and the cheap job done twice costs more than the right job done once. That is arithmetic, not salesmanship, and it happens to be true.

Document everything: before, during, after. This is the cheapest insurance in the business.

Take photographs before you touch a single joint — the whole elevation, the close-ups of the worst areas, the details of the existing mortar profile. Photograph during the work — the raked-out joints, the test panels, the mortar in the mixer, the crew at work. Photograph after — the same elevations, the same close-ups, so the transformation is visible. Date everything. Keep a simple job log: what mix went in, what the weather was, what day each elevation was pointed, when curing protection went up and came down.

This documentation does three things. First, it protects you. If

a dispute arises — a joint fails, a stain appears, a client forgets what the wall looked like before — your photographs and log are the record. Second, it educates the client; a side-by-side before-and-after is worth more than any sales pitch for the next job. Third, it makes you better. Reviewing your own work on a screen, months later, teaches you things the scaffold never did. I have caught my own bad habits in photographs that I never felt in my hands. Documentation is a craftsman's mirror.

Warranty language deserves care, because this is where good masons get into trouble and bad masons hide. Be honest about what you can stand behind and what no honest mason promises.

What you can stand behind: your workmanship. You can warrant that the joints were prepared to the specified depth, that the mortar was mixed to the specified recipe, that it was installed and cured according to the practices of the trade. If a joint you pointed fails because of something you did — a bad mix, shallow prep, a cure cut short — that is on you, and an honest mason fixes it. Say that. Put it in writing. It is the strongest selling point you have, because almost nobody else says it plainly.

What no honest mason promises: the building. You cannot warrant that a hundred-year-old wall will not move. You cannot warrant that the owner's gutters will not leak onto your joints. You cannot warrant that the foundation will not settle, that the soil will not heave, that a storm will not do what storms do. A warranty that covers everything is a warranty that means nothing, and the client who demands one is asking you to insure the building, which is not your job. The honest warranty covers your work for a defined period — commonly two to five years on workmanship in this trade — and states plainly what it does not cover: structural movement, water intrusion from other sources, damage by others, and acts of nature.

Write the warranty in plain language. If it takes a lawyer to understand it, it is not honest communication, whatever it says. A client who reads your warranty and understands exactly what is covered and what is not will trust you more, not less. Candor is a business strategy.

A few more field-tested business notes. Get a deposit that covers your materials and setup — the specialty lime, the sand, the scaffold — before the first tool comes out of the truck. Milestone payments keep cash flow honest on long jobs: prep complete, pointing complete, cure complete. Never let the final payment trail behind the cure; the job is not done until the cure is done, and the invoice should land when it is.

And keep a list of the jobs you did not take. Every year, write down the ones you walked away from and why. I will tell you in the next chapter why walking away is sometimes the most profitable decision you make. For now, understand that the business of historic repointing is built on reputation, and reputation is built one wall at a time — including the walls you had the sense not to touch.

Two more business realities finish the picture: change orders and the long game.

Change orders on historic work are not exceptions; they are the norm. You will open a wall and find conditions nobody could see from the ground — soft brick behind a sound face, a previous repair that has to come out, a lintel that is failing. The business mistake is absorbing these surprises to keep the client happy. The first time you eat a surprise, the client learns that surprises are free. The honest practice is to build the possibility of hidden conditions into the proposal itself: a written clause that says what happens when the wall reveals something unexpected — the work stops in that area, you document it, you price the additional work, and the client approves before you proceed. Clients respect this when it is stated up front. They resent it when it appears mid-job as an ambush. The difference is not the money; it is the timing of the honesty.

Price the change fairly when it comes. The temptation is to make up margin on the surprise — the client is committed, the scaffold is up, they will pay whatever you ask. Resist it. A fair change-order price on a discovered condition builds the kind of trust that produces the next three jobs. An opportunistic one produces a client who tells the story at every dinner party for a decade.

The long game is reputation, and reputation in restoration work travels through a small world. Historic commissions, preservation societies, architects who specialize in old buildings, the owners of landmark properties — they all talk to each other. One well-documented, honestly priced, beautifully executed repointing job on a visible historic building is worth more advertising than a year of anything else you could buy. And one bad one — one hard mortar on soft brick, one scarred wall, one warranty dispute handled poorly — follows you just as far.

So play the long game deliberately. Keep a portfolio with your before-and-after documentation. Ask satisfied clients for permission to show their building — not a testimonial, just the work, honestly presented. Stay in touch with the architects and preservation people who specify this work; they are the gatekeepers of the best jobs, and they remember who does it right. And every year, put some of the profit back into the

craft: a workshop, a book, a week spent learning a technique you do not have yet. The mason who is still learning at year thirty is the mason the best clients seek out at year fifty.

The business of historic repointing, at bottom, is simple: do work you can defend, charge what it is worth, write down everything, stand behind what is yours, and never let a deadline or a discount make you do something the building cannot survive. The buildings are counting on you to be the kind of contractor who thinks in decades. Be that contractor, and the business takes care of itself.

Chapter 12: Mistakes That Cost Real Money

Every mason carries a private ledger of mistakes. Mine is fifty years long. Some entries cost me money. Some cost me sleep. A few cost me jobs I was proud of, jobs I would give a great deal to do over. This chapter is the failure autopsy — the mistakes that cost real money, laid out plainly so you can learn them from the page instead of from the scaffold. Every example here is a hypothetical composite, drawn from the kinds of failures this trade produces. No real customer, no real building, no real job site is described.

Mistake one: repointing with the wrong mortar hardness.

This is the single most expensive mistake in historic masonry, and it is the mistake this entire book exists to prevent. It goes like this. A mason — maybe young, maybe just in a hurry, maybe convinced by a supplier that a modern mix is "better" — repoints an old lime-mortar wall with a hard mortar. The joints look crisp. The wall looks great. The client is happy. The check clears.

Five to ten years later the phone rings. The faces of the brick are spalling off. The wall is hollow in places. Moisture that used to travel through the soft lime joints and evaporate is now trapped, because the hard joints do not breathe, and the trapped moisture goes somewhere — into the brick. The repair for this is not repointing. The repair is brick replacement, unit by unit, at ten times the cost of the original job, and the original mason's reputation is the first casualty. I have seen walls where the only honest fix was to tear out and rebuild, because the hard mortar had destroyed the masonry it was supposed to protect.

The autopsy finding: hardness is not strength, and strength is not durability. In historic work, durability comes from compatibility — a mortar softer and more permeable than the unit. Get the hardness wrong and everything downstream is

damage.

Mistake two: grinding scars.

The angle grinder is the most useful and most dangerous tool on a restoration job. Used well, with a steady hand and a light touch, it clears old mortar fast. Used carelessly, it cuts into the brick face and leaves a scar — a groove or a nicked edge that is permanent. On hard modern brick a small scar is cosmetic. On soft historic brick a grinder scar is the beginning of the end, because the cut face is now the weakest point on the wall and water will find it.

The real cost of grinding scars is not the cosmetic damage. It is the change in the wall's weathering behavior. A scarred brick weathers faster than its neighbors. It spalls first. Then the joint next to it fails, then the brick below it. I have watched a single careless afternoon with a grinder turn into a wall of spalled brick over a decade. The fix, again, is brick replacement — expensive, and visible forever, because new brick never quite matches old.

The autopsy finding: speed in joint removal is never worth a scar. On soft units, hand tools are not old-fashioned; they are the correct technology. The grinder earns its keep on hard brick and deep joints. Everywhere else, slow down.

Mistake three: rushing the cure.

Lime mortar hardens by carbonation — it absorbs carbon dioxide from the air over weeks and months. There is no chemical shortcut that produces the same result. The mistakes here are all variations on impatience: pointing in weather that is too hot, too cold, or too windy without protection; pulling the damp covers off early because the schedule says so; pointing a wall and letting a hot Texas wind dry the face of the joint before the body of it has begun to carbonate.

A rushed cure produces a joint that looks finished and is not. The surface skins over; the interior stays soft. The first hard rain washes the uncured interior out, or the first freeze cracks the weak face. The wall has to be done again — same labor, same materials, same scaffold, twice. And the second time, the client is not paying with the same goodwill.

The autopsy finding: the cure is part of the installation, not an afterthought. Budget the cure days in the schedule, protect the work like it matters — because it is the work — and never let a deadline make the decision about when protection comes down. The weather decides. You just listen.

Mistake four: ignoring drainage and the real water source.

This is the mistake that hides behind every other mistake. A mason repoints a wall beautifully, matches the mortar perfectly, cures it with patience — and the joints fail in three years anyway, because the water was never coming through the joints in the first place. It was coming from a gutter joint pouring water down the face of the wall. It was coming from grade piled six inches above the foundation. It was coming from a sprinkler head hammering the same three feet of wall every morning. It was coming from a failed flashing detail that has been funneling roof water into the wall cavity for a decade.

Repointing does not fix water problems. Repointing fixes failed joints. If the water source is still active when you leave, your beautiful joints are just the next thing the water will destroy. The honest mason diagnoses the water before he prices the joints. Walk the property. Look up at the roof edge. Look down at the grade. Ask about the sprinklers. If the water source is something you can fix — a downspout, a grade issue — price it or refer it. If it is something you cannot fix, say so, and say what has to happen before repointing will hold.

The autopsy finding: every failed repointing job has two causes — the failed joint and the reason it failed. Fix only the first and you have bought yourself a callback.

Mistake five: over-promising timelines.

Historic work is slow. The prep is slow, the pointing is slow, the cure is slow, and the weather does what it wants. The mistake is promising a schedule built on best-case assumptions — no rain, no surprises behind the old mortar, no soft brick discovered mid-job — and then discovering reality on week two. The client is not angry that the job takes six weeks. The client is angry that you said three.

The cost here is not just the extra weeks. It is the pressure those weeks put on the crew to go faster, which is how you get grinding scars and rushed cures — mistakes one through three, all downstream of mistake five. An honest timeline with margin built in produces calm work. A dishonest timeline produces rushed work, and rushed work on historic buildings produces damage.

The autopsy finding: under-promise and over-deliver is not a slogan; it is a damage-prevention strategy. Build the weather, the unknowns, and the cure into the schedule before the client ever sees a date.

Mistake six: the jobs you should have walked away from.

Every veteran mason has them. The wall that was moving and you pointed it anyway. The client who demanded a hard

mortar on soft brick and you did what you were told instead of what was right. The building where the budget would not cover the prep and you skipped half of it to make the number work. These are the most expensive mistakes of all, because they cost money and reputation at the same time, and because you knew — or should have known — before you started.

This is where the referral rule comes in, and it is absolute: structural movement, bulging walls, anything in the load path — hire a structural engineer. Not a mason's opinion. Not a contractor's guess. A structural engineer. A wall that is bulging is telling you the structure is compromised, and no amount of repointing addresses a structural problem. Pointing a bulging wall is cosmetic work on a structural failure, and when it fails, the liability and the conscience are yours. The same goes for cracked lintels carrying load, for walls separating at corners, for any condition where the building's structure is in question. Diagnose the limit of your trade and refer past it. Every time. The referral is not a lost job; it is a kept reputation.

And here is the craftsman's code for when to say no to a job — the rules I wish someone had written down for me in year five:

- Say no when the client demands a method you know will damage the building. Your name goes on the work, not theirs.
- Say no when the budget cannot cover the preparation the wall actually needs. A cheap repointing that fails is the most expensive kind.
- Say no when the water source is unfixable and the client will not fix it. Your joints cannot survive what is coming.
- Say no when the schedule does not allow a proper cure. A deadline that breaks the work is not a deadline; it is a demolition order.
- Say no when the building needs an engineer and the client does not want one. Walk away before the wall walks away.
- Say no when your gut says the job is wrong and you cannot explain why. Fifty years has taught me the gut is usually right; it just takes the head a while to catch up.

Saying no is not losing work. Saying no is the decision that keeps you in business for fifty years instead of five. The jobs you walk away from are the jobs that would have cost you the most — in money, in sleep, and in the name you have spent a lifetime building. The wall will still be there tomorrow. Make sure your reputation is, too.

Conclusion: The Wall You Leave Behind

If you have read this far, you know the central truth of this book, and it is a short one: the old mortar was not a mistake. It was a decision. Men who had no Portland cement, no polymer additives, no laboratories to consult, built walls that have stood for two hundred years, and they did it by understanding one thing that modern construction keeps forgetting — a wall is a system, and the mortar's job is to give so the brick doesn't have to.

That is the whole of historic repointing in one sentence. Match the mortar to the wall, not the wall to your habits.

I have watched good masons destroy old walls with the best intentions. A crew gets called to an 1890s brick house with soft joints, and they do what they were trained to do on new work: mix a strong mortar, grind the joints fast, point it up tight, and walk away proud. A year later the faces of the brick are popping off in sheets, and nobody understands why, because the mortar looks perfect. The mortar is perfect. That is the problem. The mortar outlived the brick by being too strong to sacrifice itself, and the wall paid the price.

It does not have to go that way. You now know how to read an old joint — its color, its sand, its tooling, its hardness — and how to put back something that belongs there. You know the three limes and how each one cures. You know how to build a mix from local sand, how to match a color that fools the sun, how to rake a joint without scarring a single arris, how to strike a profile that the original mason would recognize as his own, and how to cure in weather that wants to ruin your work. You know the special cases that need a gentler hand, and you know the business of charging honestly for work that is honestly hard.

Here is what I want you to carry onto the scaffold, above everything else in these pages.

First: diagnose before you mix. The temptation to start mixing and pointing on day one is the most expensive habit in this trade. Walk the wall. Read every joint. Find the water. Understand what failed and why before a single trowel comes out of the bag. A test panel costs you a day and saves you a disaster.

Second: never let the new mortar be harder than the old. This is the law of this craft. It is the one rule I would put on a sign over every shop door. Harder is not better. Harder is the thing that kills the wall.

Third: protect the cure like it matters, because it is the repair. Lime mortar does most of its real work after you walk away — weeks of quiet carbonation, drawing moisture in, breathing, settling into its century-long life. A joint that cures in shade and dampness will outlast one that bakes in the wind, even if the mixes were identical. Your last act on a historic wall is not the tooling. It is the misting schedule and the burlap.

Fourth: know where your craft ends and structure begins. This book has said it in nearly every chapter and I will say it once more here, because it matters more than any recipe: when the wall is moving — bulging, leaning, cracking through units in stair-steps that keep growing — you are not looking at a mortar problem. You are looking at a structure problem, and it belongs to a structural engineer. The most professional thing a craftsman can do is name the limit of his trade and hand the job to the right hands. Walking away from work you should not do is not losing a job. It is keeping your name.

And fifth: this work is worth doing well because the walls are worth keeping. Somewhere in Texas there are brick houses, courthouses, storefronts, and farm buildings put up by men whose names nobody remembers, with mortar mixed from the sand out of the nearest creek. Those walls survived because somebody built them honestly. When you repoint them with a matching lime mortar, pointed the way they were pointed, cured the way lime wants to cure, you are not just repairing a wall. You are continuing a line of work that stretches back farther than any of us, and you are handing a building to the next generation the way it was handed to you.

That is what restoration really is. Not a product. Not a system. A promise kept across a hundred years, one joint at a time.

Go keep it.

Resources & Next Steps

If this book helped you read your old wall and you want the work done right — or you want to sharpen your own mortar craft — here is where to find us:

- **MortarMagic** — mortar color matching & the Mortar Bucket —
mortarmagic.netlify.app
- **Champion Brick Repair** — brick & masonry repair, Dallas-Fort Worth —
championbrickrepair.com — (817) 900-6324
- **Metro Foundation Repair** — pressed concrete pile

foundation repair —
metrofoundationrepair.com — (817) 523-1540

- **LintelLOCK** — the field-developed lintel replacement system — lintlerepair.com — (469) 730-0650
- **WhiteStone Construction** — stone, ranch & property work, Hamilton TX country — (254) 723-5040

Travis Nech has spent 50 years in brick, masonry, and foundation work across Texas.

About the Author

Travis Nech has spent 50 years in brick, masonry, and foundation work across Texas. He owns and operates Champion Brick Repair, Metro Foundation Repair, LintelLOCK, MortarMagic, and WhiteStone Construction.

- **Champion Brick Repair** — brick & masonry repair, Dallas-Fort Worth — championbrickrepair.com — (817) 900-6324
- **Metro Foundation Repair** — pressed concrete pile foundation repair — metrofoundationrepair.com — (817) 523-1540
- **LintelLOCK** — the field-developed lintel replacement system — lintlerepair.com — (469) 730-0650
- **MortarMagic** — mortar color matching & the Mortar Bucket — mortarmagic.netlify.app
- **WhiteStone Construction** — stone, ranch & property work, Hamilton TX country — (254) 723-5040